

M2 Cookers

599 532 474 EN

Subject: New knob graphic requires exchange of all knobs

When exchanging one of the knobs, linked to this bulletin, all knobs on the product must be exchanged.

The reason for this is to prevent quality problems with lacquered knobs damaged by hot pots and pans placed on top of them

Timing: Is valid from **week 10/2008**.

Brand: Electrolux. Design "soft", means cookers with the knobs placed on top of the hob.

Knob ANC: Is valid for knobs beginning with **349 4120-** and then all linked variants.

Present design



New design. With black index

