

NOT CONFIGURED ELECTRONIC BOARDS (Rev. 02)

In the sections:

- "Electrical equipment" in Washing machines, Washer-dryers, Dryers and Dishwashers spare part lists.
- "Diffuser" or "Cooling Unit" in Refrigeration appliances.

the "configured electronic board", identified by the first digits "973" of the spare part, is featured, where possible.

Also the "not configured electronic board" can be indicated in the same sections and with the same position.

The configuration of this board is possible only if you have the suitable equipment (software and hardware) for this type of activity and if you have taken part to the training.

It is still not possible to programme the not configured electronic boards in all Countries.

ATTENTION:

We will not accept returns of not configured electronic boards that have been wrongly ordered or that are damaged in some parts.

For any further question please contact your local Service Representative.

REVISIONS:

Revision	Date	Description
00	05/2008	Document creation
01	06/2008	Updated text
02	11/2008	Updated document for use in Refrigeration appliances