

**Demounting  
Backwagen**

© Electrolux Distriparts  
Muggenhofer Straße 135  
D-90429 Nürnberg  
Germany

Publ.-Nr.:  
**599 711 120**  
685  
EN

Fax +49 (0)911 323 1022

DGS-TDS-N  
Edition: 09.08

## Exchanging of guiding bars

Complete mounted oven

Caution: Segregate from electricity network



**Pull door off**

(Upwards)



**Demount rearbox**

Remove screws



## Branch off cable set



## Turn oven through 180°

(Bottom up)

Caution: Panel must not protrude over edge, risk of damage



## Loosening fixation of Backwagen from housing

Remove screws  
(left and right)




## Hoist Backwagen in front

Take ears out of slots on both sides



## Pull Backwagen out forward

Take ears in the rear out of slots



## Demounted Backwagen



### Demount Isolationbottom


Remove screws  
(left and right)



### Demount swords

Remove Nuts

Remove screws



### Hoist and pull out Dripping Bottom



### Demount guiding bars

Remove screws

