

Assembly the seal in cold module because of frosting.

Since there can be frost on the cold module, one should attach a **seal 243 33 50-01**
See instruction below.

1. Remove the interior from the appliance.
2. Remove the locking knob and than remove the air channel.



3. Insert the seal into the gap on the right side under the module.

