

SERVICE PIPE EXTENSION


Description:

This extension is required to lengthen the gas entrance pipe (service pipe) in the compressors in use that are already fitted to the machine, in order to make gas loading operations easier.

Solution to problems

To date the diameter of the pipe used for gas entrance in domestic compressors, also known as the service pipe, is standard to almost all compressor suppliers and has an external diameter of 6 mm.

Cut the end of the service pipe, remove any slime, insert and weld the extension pipe



Spare parts

Extension pipe code	Internal A Ø diameter	External B Ø diameter	Length
500 821 240 04	6.35 mm	6 mm	150 mm
405 515 754-1	6.2 mm	6 mm	100 mm
221 960 217-0	5 mm	6.6 mm	50 mm
238 410 211-3	2.13 mm	5.95 mm	150 mm

Revisions

Revision	Date	Description	Author	Approved by - on
00	10 / 2011	Document creation	A.D.L.	