


New front frames for build-in installation

DESCRIPTION:

All appliances from Sputnik platform have been designed with new solution for build-in mounting in furniture.
The modification will be introduced for mentioned products in week 31 of 2012 (serial numbers starting from 231XXXXX).

OLD SOLUTION:




To mount appliances with old solution one should use spare parts :

- 4x Screws wood part number: 3543208015
- 4x Spacers part number: 3558031013

Kit consisting of mentioned parts has part number: 50293036005

NEW SOLUTION:



To mount appliances with new solution one should use spare parts :

- 4x Screws wood part number: 3543300010 (4x25 mm)
- 4x Spacers part number: 3396885018

Kit consisting of mentioned parts has part number: 4055218657

MODELS INVOLVED:

PNC	DATE	MODEL	BRAND	PNC	DATE	MODEL	BRAND
949714001	20120420	ZOS35802XD	Zanussi	949716201	-----	ZOB35602XK	Zanussi
949714003	20120504	FV73XEV	Rex-Electrolux	949716203	-----	ZOB35631XA	Zanussi
949714200	20120504	FQV303XEV	Rex-Electrolux	949716204	-----	ZOB35632XA	Zanussi
949714201	20120420	EOB6850AOX	Electrolux	949716205	20120118	ZOB22601WK	Zanussi
949714202	20120626	EOB6851BOX	Electrolux	949716206	20120118	ZOB22601BK	Zanussi
949714203	20120626	EOB6851BAX	Electrolux	949716207	20120118	ZOB22601XK	Zanussi
949714204	-----	MIRAKULÖS	IKEA	949716208	20111214	ZOB25601XK	Zanussi
949714205	-----	MIRAKULÖS	IKEA	949716209	20120214	ZOB30601XK	Zanussi
949714206	-----	MIRAKULÖS	IKEA	949716210	20111021	ZOB35602XK	Zanussi
949714207	-----	GRÄNSLÖS	IKEA	949716211	20111214	ZOB35701XK	Zanussi
949714208	-----	GRÄNSLÖS	IKEA	949716212	20111214	ZOB21601XK	Zanussi
949714209	-----	GRÄNSLÖS	IKEA	949716213	20120118	ZOB25602XK	Zanussi
949714300	20120420	EOA6841AOX	Electrolux	949716214	20120323	ZOB35631XA	Zanussi
949714301	20120420	EOA6841AAX	Electrolux	949716215	20120319	ZOB35632XA	Zanussi
949714400	20120420	EOC6841AOW	Electrolux	949716216	20111214	ZOB22601XK	Zanussi
949714401	20120420	EOC6841AOX	Electrolux	949716217	20111214	ZOB25602XK	Zanussi
949714402	-----	EOC6851AAX	Electrolux	949716218	20120405	EOB3301AOX	Electrolux
949714403	-----	EOC6841AAV	Electrolux	949716219	20120412	EOB3400BOX	Electrolux
949714404	20120420	EOC6841AAX	Electrolux	949716220	20120216	EOB3410AOX	Electrolux
949714406	20120625	EOC6851BAX	Electrolux	949716221	20120403	EOB3450AOX	Electrolux
949716000	20120118	ZOB12401WK	Zanussi	949716222	20120220	EOB2000AOW	Electrolux
949716001	20111021	ZOB12401XK	Zanussi	949716224	20120220	EOB3000AOW	Electrolux
949716002	20120220	EOB1000AOW	Electrolux	949716225	20120220	EOB3000AOX	Electrolux
949716003	20120217	EOB1000AOX	Electrolux	949716226	20120220	EOB3400COW	Electrolux
949716008	20120510	ZOB12401XK	Zanussi	949716228	20120220	EOB3400COX	Electrolux
949716102	20120227	ZOB10401XA	Zanussi	949716229	20120113	EOB3400AOW	Electrolux
949716105	20120417	F13B	Rex-Electrolux	949716230	20120113	EOB3400AOK	Electrolux
949716106	20120417	F13N	Rex-Electrolux	949716231	20120214	EOB3400AOX	Electrolux
949716107	20120418	F13X	Rex-Electrolux	949716232	20120214	EOB3400BOR	Electrolux
949716200	-----	ZOB30601XK	Zanussi	949716233	20120216	EOB3400AAX	Electrolux

PNC	DATE	MODEL	BRAND	PNC	DATE	MODEL	BRAND
949716234	20120216	EOB3400BAX	Electrolux	949716285	-----	F73INEV	Rex-Electrolux
949716235	20120403	EOB3450AAX	Electrolux	949716286	-----	F73IXEV	Rex-Electrolux
949716238	20120216	EOB3000AAX	Electrolux	949716287	20120627	ROB20601WK	Rosenlew
949716239	20120312	ZOB32701BK	Zanussi	949716288	20120615	ROB35861WK	Rosenlew
949716240	20120308	ZOB32701XK	Zanussi	949716289	20120612	ROB35861XK	Rosenlew
949716241	20120404	ZOB32702BK	Zanussi	949716290	20120607	EOB2430BAX	Electrolux
949716242	20120404	ZOB32702XD	Zanussi	949716291	20120605	EOB2200COX	Electrolux
949716243	20120313	ZOB35712WK	Zanussi	949716293	20120611	ZOB32702BK	Zanussi
949716244	20120313	ZOB35712BK	Zanussi	949716294	20120416	EOB3400EAX	Electrolux
949716245	20120322	ZOB35712XK	Zanussi	949716295	20120510	ZOB35602XK	Zanussi
949716246	20120314	ZOB35772BK	Zanussi	949716296	20120424	ZOB535752X	Zanussi
949716247	20120314	ZOB35772XD	Zanussi	949716297	20120426	ZOB535712X	Zanussi
949716248	20120313	ZOB35752XD	Zanussi	949716298	20120427	ZOB532702B	Zanussi
949716249	20120308	ZOB25321XA	Zanussi	949716299	20120424	ZOB525321X	Zanussi
949716250	20120607	ZOB20601WK	Zanussi	949716300	20120424	ZOB735752X	Zanussi
949716251	20120607	ZOB20601XK	Zanussi	949716301	20120427	ZOB735701X	Zanussi
949716252	20120625	SU6030	Elektro Helios	949716302	20120504	ZOB725321X	Zanussi
949716253	20120625	SU6030X	Elektro Helios	949716303	20120510	EEB4233POX	Electrolux
949716254	20120710	ZOB30601XK	Zanussi	949716304	20120424	EEB4231POX	Electrolux
949716256	20120607	ZOB32702XD	Zanussi	949716307	20120424	EEB4230PAX	Electrolux
949716257	20111214	FOB25601WK	Faure	949716308	20120716	KOB55602XK	Zanker
949716258	20111215	FOB25601BK	Faure	949716309	20120724	EOB3410COX	Electrolux
949716259	20111215	FOB25601XK	Faure	949716310	20120726	EOB3410DAX	Electrolux
949716260	20120227	ZOB21601XK	Zanussi	949716311	-----	EEB4230POX	Electrolux
949716261	20120308	ZOB35701XK	Zanussi	949716312	-----	EOB3400DOX	Electrolux
949716262	-----	ZOB20601XK	Zanussi	949716313	-----	EOB3430AOX	Electrolux
949716263	-----	ZOB32701XK	Zanussi	949716314	-----	EOB2400AOX	Electrolux
949716264	-----	ZOB35772XD	Zanussi	949716315	-----	EOB3400BOX	Electrolux
949716265	20120724	EOB3000BAX	Electrolux	949716318	-----	ZOB30601WK	Zanussi
949716266	20120605	EOB2200BAX	Electrolux	949716319	-----	ZOB32702WK	Zanussi
949716273	20120607	EOB2430AOX	Zanussi	949716700	20120123	ZOB21301XA	Zanussi
949716274	20120724	EOB3400DOX	Electrolux	949716701	20120312	ZOB31301WK	Zanussi
949716275	20120622	EOB3400CAK	Electrolux	949716702	20120402	ZOB31301XK	Zanussi
949716276	20120606	EOB3400CAX	Electrolux	949716703	20120308	ZOB35301WK	Zanussi
949716277	20120426	F73XEV	Rex-Electrolux	949716704	20120309	ZOB35301BK	Zanussi
949716278	20120426	FQ63BV	Rex-Electrolux	949716705	20111021	ZOB35301XK	Zanussi
949716279	20120426	FQ63NV	Rex-Electrolux	949716708	20120215	EOB2200BOX	Electrolux
949716280	20120426	FQ63NV	Rex-Electrolux	949716709	20120215	EOB2200BOR	Electrolux
949716281	20120426	FQ73XEV	Rex-Electrolux	949716710	20120217	EOB2200AAX	Electrolux
949716282	20120427	FQ93NEV	Rex-Electrolux	949716711	20120313	ZOB22301XA	Zanussi
949716283	20120507	FQ93NSEV	Rex-Electrolux	949716713	20120228	ZOB21301XA	Zanussi
949716284	20120504	FQ93XEV	Rex-Electrolux	949716714	20120228	ZOB22301XA	Zanussi

PNC	DATE	MODEL	BRAND	PNC	DATE	MODEL	BRAND
949716716	20120217	EOB2200BOX	Electrolux	949717005	-----	FQ203NEV	Rex-Electrolux
949716717	20120531	EOB2200DAX	Electrolux	949717200	20120322	EOA3460AOW	Electrolux
949716718	20120424	F53B	Rex-Electrolux	949717201	20120321	EOA3460AOK	Electrolux
949716719	20120424	F53N	Rex-Electrolux	949717202	20120321	EOA3460AOX	Electrolux
949716720	20120426	F53X	Rex-Electrolux	949718100	20120315	ZOP37902XK	Zanussi
949716721	20120502	FQ53B	Rex-Electrolux	949718102	20120109	ZOP37902XK	Zanussi
949716722	20120502	FQ53N	Rex-Electrolux	949718103	20120123	ZOP38903XD	Zanussi
949716723	20120502	FQ53X	Rex-Electrolux	949718104	20111103	ZOP37902BK	Zanussi
949716724	20120703	EOB2200BON	Electrolux	949718105	20120313	ZOP37902XK	Zanussi
949716725	-----	EEB3210POX	Electrolux	949718106	20120220	ZOP38903XD	Zanussi
949716726	-----	EOB2200DOX	Electrolux	949718110	-----	ZOP37902XK	Zanussi
949716727	-----	EOB2200BOX	Electrolux	949718114	-----	SU6360X	Elektro Helios
949716900	20120313	ZOA35502XD	Zanussi	949718115	20120605	ZOP37902XK	Zanussi
949716901	20120313	ZOA35802BK	Zanussi	949718116	-----	ZOP38903XK	Zanussi
949716902	20111103	ZOA35802XD	Zanussi	949718117	20120606	EOC3430DOX	Electrolux
949716903	20120308	ZOA35701XK	Zanussi	949718118	20120606	EOC3430EAX	Electrolux
949716904	20120601	EOA2400AOW	Electrolux	949718121	20120613	EOC2420AOX	Electrolux
949716905	20120516	EOA2400AOK	Electrolux	949718122	20120613	EOC2420BAX	Electrolux
949716906	20120516	EOA2400AOX	Electrolux	949718123	-----	ZOP37902XV	Zanussi
949716907	20120216	EOA3400AAX	Electrolux	949718124	-----	KOB57602XK	Zanker
949716908	20120403	EOA3450AAX	Electrolux	949718125	20120726	EOC3410COX	Electrolux
949716909	20120308	ZOA35752XD	Zanussi	949718126	-----	EOC3410AAX	Electrolux
949716910	20120518	EOA2400AAW	Electrolux	949718127	-----	KULINARISK	IKEA
949716911	20120531	EOA2400AAK	Electrolux	949718128	-----	KULINARISK	IKEA
949716912	20120518	EOA2400AAX	Electrolux	949718129	-----	KULINARISK	IKEA
949716914	20120315	FOA20601XK	Faure	949718300	20120516	EOC2400AOW	Electrolux
949716915	20111215	FOA25601WK	Faure	949718301	20120516	EOC2400AOK	Electrolux
949716916	20111215	FOA25601BK	Faure	949718302	20120529	EOC2400AOX	Electrolux
949716917	20120214	FOA25601OK	Faure	949718303	20120320	EOC3460AOX	Electrolux
949716918	20111215	FOA25601XK	Faure	949718306	20120217	EOC3410BOX	Electrolux
949716919	20111201	FOA35801XK	Faure	949718307	-----	FOP27901XB	Faure
949716920	20120214	EOA3400AOX	Electrolux	949718308	20120516	EOC2400AAW	Electrolux
949716921	20120404	EOA3450AOX	Electrolux	949718309	20120601	EOC2400AAK	Electrolux
949716922	20120607	ZOA35752XD	Zanussi	949718310	20120601	EOC2400AAX	Electrolux
949716923	20120427	EEA4235POX	Electrolux	949718311	20120328	EOC3460AAX	Electrolux
949716924	20120511	EEA4233POX	Electrolux	949718312	-----	FOP27901XA	Electrolux
949716925	-----	EOA3430AOX	Electrolux	949718313	20120123	FOP27908WA	Faure
949717000	20120206	ZOB38903XD	Zanussi	949718314	20120123	FOP27908BA	Faure
949717001	20120312	ZOB38903XD	Zanussi	949718315	-----	FOP27908XA	Faure
949717002	20120424	FQ203XEV	Rex-Electrolux	949718316	20111222	FOP37901XA	Faure
949717003	-----	FQ203IXEV	Rex-Electrolux	949718317	20111222	FOP38903WA	Faure
949717004	-----	FQ203BEV	Rex-Electrolux	949718318	20120319	FOP38903BA	Faure

PNC	DATE	MODEL	BRAND
949718319	20120323	FOP38903XF	Faure
949718320	20120123	FOP27901WK	Faure
949718321	20120217	FOP27901BK	Faure
949718322	20120123	FOP27901XK	Faure
949718323	20120126	FOP27908XK	Faure
949718324	20120123	FOP38901WK	Faure
949718325	20111222	FOP38901BK	Faure
949718326	20111222	FOP38901XK	Faure
949718330	20120126	FOP27908WK	Faure
949718331	20120216	FOP27908BK	Faure
949722302	-----	EON1000AAX	Electrolux
949722504	20120312	ZOU21301XK	Zanussi
949722505	20120320	ZOU35762XK	Zanussi
949722507	20111213	ZOU30601XK	Zanussi
949722508	-----	ZOU30602XK	Zanussi
949722509	-----	ZOU35802XK	Zanussi
949722510	20111213	ZOU30602XK	Zanussi
949722511	20111213	ZOU35802XK	Zanussi
949722512	-----	ZOU30601WA	Zanussi
949722513	-----	ZOU30601DA	Zanussi
949722514	-----	ZOU30601XA	Zanussi
949722515	-----	ZOU35631XA	Zanussi
949722517	-----	ZOU35632XA	Zanussi
949722518	-----	ZOU35637XA	Zanussi
949722524	-----	EON3000AAX	Electrolux
949722533	20120727	EON3000AOX	Electrolux
949722537	-----	ZOU30601XK	Zanussi
949722538	-----	KOU55602XK	Zanker
949722539	-----	EON3410BOX	Electrolux
949722540	-----	EON3010AAX	Electrolux
949722541	-----	EON3410BAX	Electrolux
949722542	-----	EE2003061M	AEG
949722543	-----	EE3003061M	AEG
949722602	20111213	ZOU20301WK	Zanussi
949722603	20111213	ZOU20301XK	Zanussi
949722604	20120612	ZOU20301WK	Zanussi
949722605	20120612	ZOU20301XK	Zanussi
949722901	-----	KOU57602XK	Zanker
949722902	-----	EEO3410AOX	Electrolux
949722903	-----	EEO3410AAX	Electrolux
949722904	-----	EP3003061M	AEG

REVISION:

Revision	Date	Description	Author	Approved by-on
00	30/2012	Document Creation	Tomasz Hyzy	Gabriel Papp – 2012-08-27
01	14/2013	'New solution' - spare part codes update	Tomasz Hyzy	Gabriel Papp —2013-04-03