

EXTERNAL INTERFERENCE ON TOUCH DISHWASHERS

DESCRIPTION:

On the markets in some occasion has been detected a bad functioning of the dishwashers during the selection of the programs/options due to external interference coming from the power supply or other electronics device.


SOLUTION:

Since week 48/2011 has been implemented a "Filter", on the touch appliances interested In the appliances highlighted in the list below and produced until the week 47/2011 (serial number 147xxxxxx), in presence of problems due to external interference, is necessary to use the filter.


SPARE PARTS:

Spare Part Code Filter: 1174144012

ASSEMBLY SEQUENCE :



Consider also that a bad functioning of the dishwashers during the selection of the programs/options can due to an incorrect assembling of the transparent plastic cover (see picture below)



MODELS INVOLVED:

911437001
911437002
911437003
911437004
911437005
911437006
911437007
911437008
911437009
911447010
911677001
911677002
911677003

REVISIONS:

Revision	Date	Description	Author	Approved by - on
00	12/2012	Document Creation	OW	PC