

DOOR MAGNET REPLACEMENT

DESCRIPTION:

The lighting is not switch off due to the magnet is missing from the door and the relay can not detect it.

SOLUTION:

To solve problems in the field replace the magnet (224 00 76-03 / 0) into the door end cap.



2. Sign the door end cap where you found the relay position



3. Drill the end cap in 30 mm deeply with Ø6 mm spiral drill



4. Take a piece of insulation rubber into the drilled hole



5. Take the magnet into the drilled hole and push until is aligned with the door end cap



