

Top-ten spare parts air conditioners

Spare part number	Models
Electronics	
386 5200-81/4	FJ 1100, FJ 1700/EIR
386 5200-88/9	FJ 2200
386 5200-74/9	FL 1600
386 9004-29/5	FL 2200
386 5200-58/2	B 1600plus, B 2200
386 5200-66/5	B 2500, B 2600
Control panel	
386 5200-82/2	FJ 1100, FJ 1700/EIR, FJ 2200
386 5200-71/5	FL 1600, FL 2200
386 5200-31/9	B 1600plus, B 2200, B 2500, B 2600
Remote control	
386 5200-83/0	FJ 1100, FJ 1700/EIR, FJ 2200
386 5200-73/1	FL 1600, FL 2200
386 5200-32/7	B 1600plus, B 2200, B 2500, B 2600
Sensor for evaporator	
386 6003-19/1	FJ 1100, FJ 1700/EIR, FJ 2200, FL 1600, FL 2200,
Sealing	
386 3502-16/1 + 386 3000-38/0	FJ 1100, FJ 1700/EIR, FJ 2200
386 9002-58/8	FL 1600, FL 2200, B1600plus, B 2200, B 2500, B 2600