# **Electrolux**

## SERVICE BULLETIN REFRIGERATION

## DOOR SWITCH REMOVAL


#### **DESCRIPTION:**

Door switch has to be removed:



### **PROBLEM SOLUTION:**

In order not to damage cabinet's innerliner, put 2 pieces of paper or thin plastic as shown in picture below (1). Then use screwdriver or thin plate to lever the switch (2)(3).



#### **REVISON:**

revision	Date	Description	Autor	Approved by - date
00	03 / 2013	Document Creation	K.L.	

EN	599 76 38-38	03 / 2013 Rev.00	Spares Documentation - KL	1/1
----	--------------	------------------	---------------------------	-----