


PUMP BODY AND STRAINER FILTER EXCHANGE

DESCRIPTION:


Old type of strainer filter (part number 1327150106), filter cap (part number 1323823037) and pump body is no longer available. It can be replaced by set of new ones.

SOLUTION:

If there is a need to change strainer filter, filter cap and/or pump body, the entire set has to be replaced.



1. Old pump body, filter and cap set.



2. New pump body, filter and cap set.

SPARE PART NUMBER:

Old spare part code			New spare part code	
Pump body	Strainer filter	Filter cap	Pump body	Strainer filter assembly
1325318010	1327150106	1323823037	1327915003	1327658108
1325318127			1327915102	
1325318812			1327915409	
1326878202			1327915300	
1326999024			1327915409	
1327146211			1327915003	
1327146229			1327915003	
1327146310			1327915102	
1327146328			1327915102	
1327146336			1327915102	
1327146724			1327915300	

MODELS INVOLVED:

Any appliance with filter 1327150106.

PNC	MODEL	BRAND	PNC	MODEL	BRAND
91452080002	P68	Zoppas	91452910803	EWS10277W	Electrolux
91452080003	P68	Zoppas	91452910804	EWS10277W	Electrolux
91452080202	P611	Zoppas	91452910902	EWS10470S	Electrolux
91452080203	P611	Zoppas	91452910903	EWS10470S	Electrolux
91452080402	ZF206	Zoppas	91452911002	RWS10470S	Rex-Electrolux
91452080403	ZF206	Zoppas	91452911003	RWS10470S	Rex-Electrolux
91452080602	RWP1017W	Rex-Electrolux	91452911402	ZWS7108	Zanussi
91452080603	RWP1017W	Rex-Electrolux	91452911403	ZWS7108	Zanussi
91452080702	RWP8170W	Rex-Electrolux	91452911404	ZWS7108	Zanussi
91452080703	RWP8170W	Rex-Electrolux	91452911502	ZWS7128	Zanussi
91452080802	RWP6170W	Rex-Electrolux	91452911503	ZWS7128	Zanussi
91452080803	RWP6170W	Rex-Electrolux	91452911602	PL1046D	Zoppas
91452080902	RWP8075W	Rex-Electrolux	91452911603	PL1046D	Zoppas
91452080903	RWP8075W	Rex-Electrolux	91452911604	PL1046D	Zoppas
91452081002	RWP10075W	Rex-Electrolux	91452911902	RWS10470W	Rex-Electrolux
91452081003	RWP10075W	Rex-Electrolux	91452911903	RWS10470W	Rex-Electrolux
91452081102	RWP12075W	Rex-Electrolux	91452911904	RWS10470W	Rex-Electrolux
91452081103	RWP12075W	Rex-Electrolux	91452912003	RWS12670W	Rex-Electrolux
91452081201	EWP10075W	Electrolux	91452912004	RWS12670W	Rex-Electrolux
91452081203	EWP10075W	Electrolux	91452912102	EWS12470W	Electrolux
91452081602	ZF2461	Zoppas	91452912200	EWS10470W	Electrolux
91452090002	RWP12470W	Rex-Electrolux	91452912202	EWS10470W	Electrolux
91452090003	RWP12470W	Rex-Electrolux	91452912203	EWS10470W	Electrolux
91452090200	JLWM1404	John Lewis	91452912300	EWS126510W	Electrolux
91452090201	JLWM1404	John Lewis	91452912301	EWS126510W	Electrolux
91452183900	EWM126410W	Electrolux	91452912302	EWS126510W	Electrolux
91452256500	EWFM14480W	Electrolux	91452912400	EWS106410W	Electrolux
91452256501	EWFM14480W	Electrolux	91452912401	EWS106410W	Electrolux
91452257201	EWFM14480W	Electrolux	91452912500	EWS106410S	Electrolux
91452259700	EWM147410W	Electrolux	91452912501	EWS106410S	Electrolux
91452259900	EWM147410W	Electrolux	91452912600	EWS126410W	Electrolux
91452266100	EFW147580W	Electrolux	91452912601	EWS126410W	Electrolux
91452266500	EFW147480W	Electrolux	91452912700	EWS126410W	Electrolux
91452266900	EFW167580W	Electrolux	91452912800	EWS126410W	Electrolux
91452267000	EFW167580W	Electrolux	91452912801	EWS126410W	Electrolux
91452267800	EFW147580W	Electrolux	91452912900	RWS126510W	Rex-Electrolux
91452268600	EFW147480W	Electrolux	91452913000	RWS106410W	Rex-Electrolux
91452269200	EFW167580W	Electrolux	91452913200	PWS61070	Zoppas
91452269400	EFW127570W	Electrolux	91452913300	EWS106417W	Electrolux
91452269500	EFW167480W	Electrolux	91452913400	EWS106410W	Electrolux
91452281000	EWM147410W	Electrolux	91452913500	RENLIGFWM	IKEA
91452281500	EWM147410W	Electrolux	91452913600	RENLIGFWM	IKEA
91452284500	EWM147410W	Electrolux	91452920001	EWS10570W	Electrolux
91452290400	EFW127450W	Electrolux	91452920002	EWS10570W	Electrolux
91452290500	EFW127450W	Electrolux	91452920201	EWS10770W	Electrolux
91452290600	EFW127450W	Electrolux	91452920600	EWS106540W	Electrolux

PNC	MODEL	BRAND
91452290700	EWF147450W	Electrolux
91452290800	EWF147450W	Electrolux
91452290900	EWF147450W	Electrolux
91452291000	RWF147450W	Rex-Electrolux
91452291200	EWF167480W	Electrolux
91452900001	EWS8070W	Electrolux
91452900102	EWS10070W	Electrolux
91452900103	EWS10070W	Electrolux
91452900301	RWS10079W	Rex-Electrolux
91452900303	RWS10079W	Rex-Electrolux
91452900602	EWS10170W	Electrolux
91452900603	EWS10170W	Electrolux
91452901301	ZWS588	Zanussi
91452901302	ZWS588	Zanussi
91452901303	ZWS588	Zanussi
91452901304	ZWS588	Zanussi
91452901802	ZWS5883	Zanussi
91452901803	ZWS5883	Zanussi
91452901804	ZWS5883	Zanussi
91452901902	ZWS5108	Zanussi
91452901903	ZWS5108	Zanussi
91452901904	ZWS5108	Zanussi
91452902002	PL846	Zoppas
91452902003	PL846	Zoppas
91452902004	PL846	Zoppas
91452902202	RWS10170W	Rex-Electrolux
91452902203	RWS10170W	Rex-Electrolux
91452902204	RWS10170W	Rex-Electrolux
91452902602	EWS7170W	Electrolux
91452902702	EWS8170W	Electrolux
91452902703	EWS8170W	Electrolux
91452902800	ZWS568	Zanussi
91452902801	ZWS568	Zanussi
91452902802	ZWS568	Zanussi
91452902803	ZWS568	Zanussi
91452902900	ZWS668	Zanussi
91452902901	ZWS668	Zanussi
91452902903	ZWS668	Zanussi
91452903000	ZWS588	Zanussi
91452903001	ZWS588	Zanussi
91452903002	ZWS588	Zanussi
91452903003	ZWS588	Zanussi
91452903100	ZWS688	Zanussi
91452903101	ZWS688	Zanussi
91452903102	ZWS688	Zanussi
91452903103	ZWS688	Zanussi
91452903201	ZWS5108	Zanussi
91452903202	ZWS5108	Zanussi

PNC	MODEL	BRAND
91452920601	EWS106540W	Electrolux
91452920700	EWS126540W	Electrolux
91452920701	EWS126540W	Electrolux
91452920800	EWS106430W	Electrolux
91452920801	EWS106430W	Electrolux
91452930001	EWS12971W	Electrolux
91452930101	EWS14971W	Electrolux
91460400403	EWV12470W	Electrolux
91460400503	EWV12470W	Electrolux
91460400802	ZKG2105	Zanussi
91460400803	ZKG2105	Zanussi
91460400903	ZKG2125	Zanussi
91460401103	ZWD1460	Zanussi
91460401302	ZKG2145	Zanussi
91460401501	EWV12470W	Electrolux
91460401502	EWV12470W	Electrolux
91460401602	ZKG2125	Zanussi
91460401603	ZKG2125	Zanussi
91460402302	WD8126EL	NORLAND
91460402303	WD8126EL	NORLAND
91460402602	EWV12470W	Electrolux
91460402701	EWV12470W	Electrolux
91460402702	EWV12470W	Electrolux
91460402802	ZWD12270W1	Zanussi
91460402901	ZWD14270W1	Zanussi
91460403003	ZWD16270W1	Zanussi
91460403101	ZWD12270S1	Zanussi
91460403402	ZWD12270G1	Zanussi
91460403700	ZKG2145	Zanussi
91460403800	WD10146EL	NORLAND
91460403901	ZKG2105	Zanussi
91460403902	ZKG2105	Zanussi
91460404402	ZKG2125	Zanussi
91460404500	EWV126410W	Electrolux
91460420304	KT2255	Elektro Helios
91460420604	ZKH2125	Zanussi
91460420702	ZKH2145	Zanussi
91460420803	PLA714D	Zoppas
91460421102	ZKH2145	Zanussi
91460421202	ZKH2105	Zanussi
91460421500	EWV14480W	Electrolux
91460421501	EWV14480W	Electrolux
91460421802	AWV12480W	Arthur Martin Electrolux
91460422001	AWV14480W	Arthur Martin Electrolux
91460422102	ZKH2125	Zanussi
91460422400	EWV12480W	Electrolux
91460422402	EWV12480W	Electrolux
91460422800	WTF8480.7	Zanker

PNC	MODEL	BRAND	PNC	MODEL	BRAND
91452903203	ZWS5108	Zanussi	91460422801	WTF8480.7	Zanker-Electrolux
91452903500	EWS106210W	Electrolux	91460422900	PKH71470	Zoppas
91452903501	EWS106210W	Electrolux	91460423000	EWV147410W	Electrolux
91452903600	EWS86110W	Electrolux	91460423100	EWV147410W	Electrolux
91452903700	EWS86110W	Electrolux	91460423200	EWV147410W	Electrolux
91452903701	EWS86110W	Electrolux	91460423300	KT2256	Elektro Helios
91452903800	RWS106119W	Rex-Electrolux	91460423400	WTF8481_7	Zanker
91452903900	EWS106110W	Electrolux	91460430502	EWV16781W	Electrolux
91452903901	EWS106110W	Electrolux	91460431002	EWV14581W	Electrolux
91452904000	RWS10072W	Rex-Electrolux	91460431202	EWV16489W	Electrolux
91452904001	RWS10072W	Rex-Electrolux	91460431203	EWV16489W	Electrolux
91452904002	RWS10072W	Rex-Electrolux	91460431503	EWV14582W	Electrolux
91452904100	RWS106200W	Rex-Electrolux	91460432102	JLWD1609	John Lewis
91452904200	PWS6850	Zoppas	91460432202	ZWD14581W1	Zanussi
91452910002	EWS10470W	Electrolux	91460432301	ZWD14581S1	Zanussi
91452910003	EWS10470W	Electrolux	91460433000	WTF9680.7	Zanker
91452910004	EWS10470W	Electrolux	91460433001	WTF9680.7	Zanker
91452910102	EWS12470W	Electrolux	91460433100	EWV167580W	Electrolux
91452910103	EWS12470W	Electrolux	91460433200	JLWD1609	John Lewis
91452910200	RENLIGFWM	IKEA	91460433300	EWV127470W	Electrolux
91452910201	RENLIGFWM	IKEA	91460433400	EWV147470W	Electrolux
91452910402	EWS10670W	Electrolux	91460433500	EWV127470W	Electrolux
91452910403	EWS10670W	Electrolux	91460433700	EWV147470W	Rex-Electrolux
91452910404	EWS10670W	Electrolux	91460433800	WTF9681_7	Zanker
91452910502	EWS12670W	Electrolux	91460433900	EWV147472W	Electrolux
91452910802	EWS10277W	Electrolux			

REVISION:

Revision	Date	Description	Author	Approved by - on
00	07/2013	Document Creation	Krzysztof Łazowski	Fabio Scodeller – 23.10.2013