


### TOP DOOR OVEN COVER MELTED ON PYRO OVENS

When the pyrolytic ovens Apollo cover door is melted, it may be due to one of the following three reasons mentioned below:

1. It was a wrong Door cover (non-pyro Door cover) in the factory installed. The Technician can see this from the following pictures, or at the part numbers on the Door cover.

Here are the pictures of the various Door covers.



HDC06144.JPG

Fig. 1

2. The cooling fan is blocked or has no function, then, depending on the temperature, the Door cover can also melt.

3. The cooling fan is not turning at Pyro- function with the fast speed (e.g. in case of incorrect wiring).

#### REVISION:

Revision	Date	Description	Author	Approved by - on
00	09/2013	Document Creation	FV	