

Wrong time displayed on VCU

DESCRIPTION:


In ovens equipped with VCU, time runs slower by 1 to 3 minutes per month. Currently VCU software variants are reworked according to table below.

New firmware number
FV03BE055
FV05BE055
FV06BE055
FV05BF004
FV06BF004
FVS2BE050
FVS5BE050
FVS6BE050
FVS5BF004
FVS6BF004
FV05CA032
FV06CA032

SOLUTION:

To correct this issue, it is required to update software. Also, this correction is possible for appliances produced between 2010 and 2012 when Sidekick was used for VCU.

Firstly, it is required to create an update in Sidekick to receive the new software files. During searching customer PNC, new software will be provided automatically. Later, verify if the file is updated for customer PNC, according to instructions below:




1. Open Sidekick and go to section 'Appliance information'

Boards identification

94418725000


Results for '944187250 00'

Appliance Information	
PNC	944187250
ELC	00
Prog	4
Factory	DGT
Production Date	20140530
Brand Name	AEG
Model	BS8354801M
VCU	
Service Kit Code	974 944187250-00/7
Spare Part Code	561 03 22-00 / 9
Configured Board Firmware	561 9451 04 [002]
Firmware ANC	561 9450 00 H [VU1] <u>FV05CA032</u>
Product	OUI
Platform	HOTSWCFG
Configuration ANC	561 9441 80 E [***] CE07CA035
OVC3000	
Service Kit Code	982561 93 64-10 / 3
Spare Part Code	-
Configured Board Firmware	561 9364 10 [000]
Firmware ANC	561 9435 00 B [O32] 230V Etna Steamer
Product	OC
Platform	HOTSW
Configuration ANC	-



4055151296
3Pin MACS,
RoundPlug

Tests and Alarms



2. Enter customer PNC and check Firmware number

MODELS INVOLVED:

List of PNCs involved in the above way of repairing is as follows:

PNC	MODEL	BRAND
94418588600	BS8304021M	AEG Electrolux
94418588602	BS8304021M	AEG
94418588800	BS8304001M	AEG
94418588801	BS8304001M	AEG
94418588900	BS8304001M	AEG Electrolux
94418588901	BS8304001M	AEG
94418588902	BS8304001M	AEG
94418588903	BS8304001M	AEG
94418589000	BS8304021M	AEG Electrolux
94418589001	BS8304021M	AEG
94418589002	BS8304021M	AEG
94418590800	BS9304001M	AEG Electrolux
94418590801	BS9304001M	AEG
94418590802	BS9304001M	AEG
94418590803	BS9304001M	AEG
94418596700	BP9314001M	AEG
94418596900	BS9304001M	AEG Electrolux
94418596901	BS9304001M	AEG
94418596902	BS9304001M	AEG
94418596903	BS9304001M	AEG
94418597000	BS9304401M	AEG
94418597001	BS9304401M	AEG
94418597100	BS9314401M	AEG
94418597101	BS9314401M	AEG
94418597102	BS9314401M	AEG
94418597200	BP9304151M	AEG
94418702900	BS931440PM	AEG
94418702901	BS931440PM	AEG
94418704200	BS8304001M	AEG
94418704201	BS8304001M	AEG
94418704202	BS8304001M	AEG
94418704300	BS8304021M	AEG
94418704301	BS8304021M	AEG
94418704302	BS8304021M	AEG
94418704400	BP9304001M	AEG
94418704401	BP9304001M	AEG
94418704500	BS9304001M	AEG
94418704501	BS9304001M	AEG
94418704502	BS9304001M	AEG
94418704600	BP9304151M	AEG

PNC	MODEL	BRAND
94418704601	BP9304151M	AEG
94418704700	BP9314001M	AEG
94418704701	BP9314001M	AEG
94418704702	BP9314001M	AEG
94418704703	BP9314001M	AEG
94418704802	BS9314401M	AEG
94418704803	BS9314401M	AEG
94418704900	BP931400PM	AEG
94418704901	BP931400PM	AEG
94418704902	BP931400PM	AEG
94418704903	BP931400PM	AEG
94418705002	BS931440PM	AEG
94418705003	BS931440PM	AEG
94418705100	BP8314021M	AEG
94418705101	BP8314021M	AEG
94418705102	BP8314021M	AEG
94418705103	BP8314021M	AEG
94418705200	BP8314001M	AEG
94418705201	BP8314001M	AEG
94418705202	BP8314001M	AEG
94418705203	BP8314001M	AEG
94418705300	BS8314001M	AEG
94418705301	BS8314001M	AEG
94418705302	BS8314001M	AEG
94418705400	BS8314021M	AEG
94418705401	BS8314021M	AEG
94418705402	BS8314021M	AEG
94418705501	BS8314001M	AEG
94418705502	BS8314001M	AEG
94418705600	BP9314001M	AEG
94418705603	BP9314001M	AEG
94418705701	BS9314001M	AEG
94418705702	BS9314001M	AEG
94418705900	BS9314001M	AEG
94418705901	BS9314001M	AEG
94418706000	BP8314021M	AEG
94418706001	BP8314021M	AEG
94418706002	BP8314021M	AEG
94418706003	BP8314021M	AEG
94418706100	BP8314001M	AEG

PNC	MODEL	BRAND
94418706101	BP8314001M	AEG
94418706102	BP8314001M	AEG
94418706103	BP8314001M	AEG
94418706201	BS8314401M	AEG
94418706202	BS8314401M	AEG
94418706203	BS8314401M	AEG
94418706301	BS8314421M	AEG
94418706302	BS8314421M	AEG
94418706303	BS8314421M	AEG
94418706401	BS9314401M	AEG
94418706402	BS9314401M	AEG
94418706601	BS9314001M	AEG
94418706602	BS9314001M	AEG
94418706700	BP8314001M	AEG
94418706701	BP8314001M	AEG
94418706702	BP8314001M	AEG
94418706703	BP8314001M	AEG
94418706801	BS8314001M	AEG
94418706802	BS8314001M	AEG
94418706900	BE9314071M	AEG
94418706901	BE9314071M	AEG
94418707301	BS9354151M	AEG
94418711200	BP931400CM	AEG
94418711201	BP931400CM	AEG
94418711302	BS931440CM	AEG
94418712102	BS931440NM	AEG
94418712103	BS931440NM	AEG
94418714600	BS9354071M	AEG
94418714601	BS9354071M	AEG
94418714700	BP8304001M	AEG
94418714702	BP8304001M	AEG
94418718800	BS9354001M	AEG
94418718801	BS9354001M	AEG
94418719400	BS935400WM	AEG
94418719401	BS935400WM	AEG
94418722400	BP5931400M	AEG
94418722500	BS5931400M	AEG
94418722600	BS5831402M	AEG
94418725000	BS8354801M	AEG
94418725500	BS835480WM	AEG
94418725800	BS836480NM	AEG
94418726000	BS836480EM	AEG
94418728900	BP8304601M	AEG

PNC	MODEL	BRAND
94418729000	BP831460WM	AEG
94418729100	BP831460SM	AEG
94418729200	BP831460KM	AEG
94418729400	BS8304101M	AEG
94418729500	BS831410WM	AEG
94418729700	BS831410SM	AEG
94418729800	BS831410KM	AEG
94418732700	BS8314021M	AEG
94418733700	BE9314171M	AEG
94418734800	BS8314721M	AEG
94418736200	BS8304701M	AEG
94418736500	BS831470WM	AEG
94418736600	BS9304701M	AEG
94418748800	BS8354801M	AEG
94418749000	BS835480WM	AEG
94418758000	BS1835480X	AEG
94427110100	EBSL7SP	Electrolux
94427110101	EBSL7SP	Electrolux
94427110102	EBSL7SP	Electrolux
94427110200	EBSL7CN	Electrolux
94427110201	EBSL7CN	Electrolux
94427110202	EBSL7CN	Electrolux
94427110400	EBKSL7CN	Electrolux
94427110401	EBKSL7CN	Electrolux
94427110500	EBSL70SP	Electrolux
94427110501	EBSL70SP	Electrolux
94427110600	EBSL70CN	Electrolux
94427110601	EBSL70CN	Electrolux
94427112000	EBSL60CN	Electrolux
94427112001	EBSL60CN	Electrolux
94427112200	EBSL80CN	Electrolux
94427118800	BOGEPM	Electrolux
94427118802	EBSL7EEV	Electrolux
94427123000	EBSL7SP	Electrolux
94427123100	EBSL7CN	Electrolux
94427123200	EBKSL7SP	Electrolux
94427123300	EBKSL7CN	Electrolux
94427123400	EBSL70SP	Electrolux
94427123500	EBSL70CN	Electrolux
94427125100	EBSL7EEV	Electrolux
94427126000	EBSL6SP	Electrolux
94427126001	EBSL6SP	Electrolux
94427126100	EBSL6CN	Electrolux

PNC	MODEL	BRAND
94427126200	EBKSL6SP	Electrolux
94427126300	EBKSL6CN	Electrolux
94427126400	EBSL60SP	Electrolux
94427126500	EBSL60CN	Electrolux
94427126501	EBSL60CN	Electrolux
94427126600	EBSL80SP	Electrolux
94427126601	EBSL80SP	Electrolux
94427126700	EBSL80CN	Electrolux
94427130600	EBSL7SP	Electrolux
94427130601	EBSL7SP	Electrolux
94427130700	EBSL7CN	Electrolux
94427130701	EBSL7CN	Electrolux
94427130800	EBKSL7SP	Electrolux
94427130801	EBKSL7SP	Electrolux
94427130900	EBKSL7CN	Electrolux
94427130901	EBKSL7CN	Electrolux
94427131000	EBSL70SP	Electrolux
94427131001	EBSL70SP	Electrolux
94427131100	EBSL70CN	Electrolux
94427131101	EBSL70CN	Electrolux
94427132900	EBSL7EEV	Electrolux
94427132901	EBSL7EEV	Electrolux
94418218000	JLBIOS617	John Lewis
94418221300	QCE5765K	Husqvarna Electrolux
94418221304	QCE5765K	Husqvarna Electrolux
94418221305	QCE5765K	Husqvarna Electrolux
94418221307	QCE5765K	Husqvarna Electrolux
94418221400	QCE5765X	Husqvarna Electrolux
94418221404	QCE5765X	Husqvarna Electrolux
94418221405	QCE5765X	Husqvarna Electrolux
94418221406	QCE5765X	Husqvarna Electrolux
94418221407	QCE5765X	Husqvarna Electrolux
94418221500	IED6900-RF	Voss-Electrolux
94418221504	IED6900-RF	Voss-Electrolux
94418221505	IED6900-RF	Voss-Electrolux
94418226200	IEL9800-HV	Voss-Electrolux
94418226201	IEL9800-HV	Voss-Electrolux
94418226300	IEL9800-RF	Voss-Electrolux
94418226301	IEL9800-RF	Voss-Electrolux

PNC	MODEL	BRAND
94418226700	QCE5745X	Husqvarna Electrolux
94418226701	QCE5745X	Husqvarna Electrolux
94418226702	QCE5745X	Husqvarna Electrolux
94418226703	QCE5745X	Husqvarna Electrolux
94418226704	QCE5745X	Husqvarna Electrolux
94418226802	QCE5766K	Husqvarna Electrolux
94418226803	QCE5766K	Husqvarna Electrolux
94418226902	QCE5766X	Husqvarna Electrolux
94418226903	QCE5766X	Husqvarna Electrolux
94418227000	IED6901-RF	Voss-Electrolux
94418227002	IED6901-RF	Voss-Electrolux
94418227003	IED6901-RF	Voss-Electrolux
94418227201	IEL9800-HV	Voss-Electrolux
94418227202	IEL9800-HV	Voss-Electrolux
94418227203	IEL9800-HV	Voss-Electrolux
94418227204	IEL9800-HV	Voss-Electrolux
94418227301	IEL9800-RF	Voss-Electrolux
94418227302	IEL9800-RF	Voss-Electrolux
94418227303	IEL9800-RF	Voss-Electrolux
94418227304	IEL9800-RF	Voss-Electrolux
94418410200	EOB8851AAX	Electrolux
94418410201	EOB8851AAX	Electrolux
94418410300	EOB8851AAX	Electrolux
94418410301	EOB8851AAX	Electrolux
94418410400	EOB8851AAX	Electrolux
94418410401	EOB8851AAX	Electrolux
94418410500	EOB8851AOX	Electrolux
94418410501	EOB8851AOX	Electrolux
94418410502	EOB8851AOX	Electrolux
94418415800	EOA5851AAX	Electrolux
94418415801	EOA5851AAX	Electrolux
94418419000	EOB5851AOX	Electrolux
94418419001	EOB5851AOX	Electrolux
94418424000	EOC5851AAX	Electrolux
94418424100	EOC5851AAX	Electrolux
94418424300	EOC5851AAX	Electrolux
94418424301	EOC5851AAX	Electrolux
94418424501	EOC5851AOX	Electrolux
94418424502	EOC5851AOX	Electrolux

PNC	MODEL	BRAND
94418425500	EOB8841AOX	Electrolux
94418425501	EOB8841AOX	Electrolux
94418429800	EOC5851WOX	Electrolux
94418429900	EOB8841WOX	Electrolux
94418429901	EOB8841WOX	Electrolux
94418431201	EOB8851AAX	Electrolux
94418431202	EOB8851AAX	Electrolux
94418431203	EOB8851AAX	Electrolux
94418432600	EOB8851AAX	Electrolux
94418432601	EOB8851AAX	Electrolux
94418432602	EOB8851AAX	Electrolux
94418432603	EOB8851AAX	Electrolux
94418432702	EOB8851AAX	Electrolux
94418432703	EOB8851AAX	Electrolux
94418432801	EOB8851AAX	Electrolux
94418432802	EOB8851AAX	Electrolux
94418432902	EOB8851AOX	Electrolux
94418432903	EOB8851AOX	Electrolux
94418433100	EOA5851AAX	Electrolux
94418433101	EOA5851AAX	Electrolux
94418433102	EOA5851AAX	Electrolux
94418433201	EOB5851AOX	Electrolux
94418433202	EOB5851AOX	Electrolux
94418433600	EOC5851AAX	Electrolux
94418433601	EOC5851AAX	Electrolux
94418433602	EOC5851AAX	Electrolux
94418433603	EOC5851AAX	Electrolux
94418433700	EOC5851AAX	Electrolux
94418433701	EOC5851AAX	Electrolux
94418433702	EOC5851AAX	Electrolux
94418433703	EOC5851AAX	Electrolux
94418433800	EOC5851AAX	Electrolux
94418433801	EOC5851AAX	Electrolux
94418433802	EOC5851AAX	Electrolux
94418433803	EOC5851AAX	Electrolux
94418433900	EOC5851AOX	Electrolux
94418433901	EOC5851AOX	Electrolux
94418433902	EOC5851AOX	Electrolux
94418433903	EOC5851AOX	Electrolux
94418434000	EOC5851AOX	Electrolux
94418434001	EOC5851AOX	Electrolux
94418434100	EOC5851AAV	Electrolux
94418434101	EOC5851AAV	Electrolux

PNC	MODEL	BRAND
94418434700	EOC5851WOX	Electrolux
94418434701	EOC5851WOX	Electrolux
94418434702	EOC5851WOX	Electrolux
94418434703	EOC5851WOX	Electrolux
94418434800	EOB8841WOX	Electrolux
94418434801	EOB8841WOX	Electrolux
94418434802	EOB8841WOX	Electrolux
94418434803	EOB8841WOX	Electrolux
94418434902	EEB8585POX	Electrolux
94418434903	EEB8585POX	Electrolux
94418441401	EOB8851VAX	Electrolux
94418441502	EOB8851VAX	Electrolux
94418441503	EOB8851VAX	Electrolux
94418441900	EOC5851AAV	Electrolux
94418441901	EOC5851AAV	Electrolux
94418441902	EOC5851AAV	Electrolux
94418441903	EOC5851AAV	Electrolux
94418445300	EOC95851AX	Electrolux
94418445301	EOC95851AX	Electrolux
94418445302	EOC95851AX	Electrolux
94418445500	EOB95851AX	Electrolux
94418445501	EOB95851AX	Electrolux
94418445900	EOB8851AAX	Electrolux
94418447700	EOB95851BX	Electrolux
94418447701	EOB95851BX	Electrolux
94418448100	EOB98851AX	Electrolux
94418448101	EOB98851AX	Electrolux
94418448400	EOB9851VAX	Electrolux
94418448500	EOB9851VAX	Electrolux
94418450200	FVS400XEV	Rex-Electrolux
94418451000	EOS860X	Electrolux
94418452800	EKS860X	Electrolux
94418453700	EOB8851AAX	Electrolux
94418453800	EOB8851AOX	Electrolux
94418460500	EOP800X	Electrolux
94418461400	EKP800V	Electrolux
94418463400	EOB9851XAX	Electrolux
94418465700	OOS700NX	Electrolux
94418576200	BE9314071M	AEG Electrolux
94418578600	BP9004001M	AEG Electrolux
94418578700	BP9314001M	AEG Electrolux
94418579100	BS9304001M	AEG Electrolux
94418579300	BS9304401M	AEG Electrolux

PNC	MODEL	BRAND
94418579301	BS9304401M	AEG
94418580000	BP9304151M	AEG Electrolux
94418580300	BS9304001M	AEG Electrolux
94418580301	BS9304001M	AEG
94418580302	BS9304001M	AEG
94418580303	BS9304001M	AEG
94418586900	BP8314001M	AEG Electrolux
94418587000	BS8304001M	AEG Electrolux
94418587002	BS8304001M	AEG
94418587003	BS8304001M	AEG
94406603300	EB4SL90SP	Electrolux
94406603301	EB4SL90SP	Electrolux
94406603302	EB4SL90SP	Electrolux
94406603400	EB4SL90CN	Electrolux
94406603401	EB4SL90CN	Electrolux
94406603402	EB4SL90CN	Electrolux
94406603500	EB4GL90SP	Electrolux
94406603501	EB4GL90SP	Electrolux
94406603502	EB4GL90SP	Electrolux
94406603600	EB4GL90CN	Electrolux
94406603601	EB4GL90CN	Electrolux
94406603602	EB4GL90CN	Electrolux
94406603700	KM8403021M	AEG
94406603701	KM8403021M	AEG
94406603702	KM8403021M	AEG
94406603800	KM8403021M	AEG
94406603801	KM8403021M	AEG
94406603802	KM8403021M	AEG
94406603900	KM8403001M	AEG
94406603901	KM8403001M	AEG
94406604000	KM8403001M	AEG
94406604001	KM8403001M	AEG
94406604002	KM8403001M	AEG
94406604100	QCK5770X	Husqvarna Electrolux
94406604101	QCK5770X	Husqvarna Electrolux
94406604102	QCK5770X	Husqvarna Electrolux
94406604200	IKC6800-RF	Voss-Electrolux
94406604201	IKC6800-RF	Voss-Electrolux
94406604202	IKC6800-RF	Voss-Electrolux
94406604300	KR8403021M	AEG
94406604301	KR8403021M	AEG
94406604302	KR8403021M	AEG

PNC	MODEL	BRAND
94406604400	KR8403021M	AEG
94406604401	KR8403021M	AEG
94406604600	KR8403001M	AEG
94406604601	KR8403001M	AEG
94406604700	EVY7800AOX	Electrolux
94406604701	EVY7800AOX	Electrolux
94406604702	EVY7800AOX	Electrolux
94406604703	EVY7800AOX	Electrolux
94406604800	EVY7800AAX	Electrolux
94406604801	EVY7800AAX	Electrolux
94406604802	EVY7800AAX	Electrolux
94406604803	EVY7800AAX	Electrolux
94406605100	EVY6800AAX	Electrolux
94406605101	EVY6800AAX	Electrolux
94406605102	EVY6800AAX	Electrolux
94406605103	EVY6800AAX	Electrolux
94406606100	EVY7800AAX	Electrolux
94406606101	EVY7800AAX	Electrolux
94406606102	EVY7800AAX	Electrolux
94406606103	EVY7800AAX	Electrolux
94406606400	EVY6800AAX	Electrolux
94406606401	EVY6800AAX	Electrolux
94406606402	EVY6800AAX	Electrolux
94406606403	EVY6800AAX	Electrolux
94406607400	KE8404001M	AEG
94406607401	KE8404001M	AEG
94406607402	KE8404001M	AEG
94406607501	KE8404001M	AEG
94406607502	KE8404001M	AEG
94406607701	KE8404021M	AEG
94406607702	KE8404021M	AEG
94406607703	KE8404021M	AEG
94406608100	KS8400521M	AEG
94406608101	KS8400521M	AEG
94406608102	KS8400521M	AEG
94406608301	KS8404001M	AEG
94406608302	KS8404001M	AEG
94406608303	KS8404001M	AEG
94406608501	KS8404021M	AEG
94406608502	KS8404021M	AEG
94406608503	KS8404021M	AEG
94406608601	KS8404021M	AEG
94406608602	KS8404021M	AEG

PNC	MODEL	BRAND
94406608603	KS8404021M	AEG
94406608701	QCK5760X	Husqvarna Electrolux
94406608702	QCK5760X	Husqvarna Electrolux
94406608703	QCK5760X	Husqvarna Electrolux
94406608801	KE8404021M	AEG
94406608802	KE8404021M	AEG
94406608803	KE8404021M	AEG
94406608900	KS8404021M	AEG
94406608901	KS8404021M	AEG
94406608902	KS8404021M	AEG
94406608903	KS8404021M	AEG
94406609200	QCK5780X	Husqvarna Electrolux
94406609400	EVY5841AAX	Electrolux
94406609401	EVY5841AAX	Electrolux
94406609700	EVY3841AOX	Electrolux
94406609701	EVY3841AOX	Electrolux
94406610000	EVY8840AOX	Electrolux
94406610001	EVY8840AOX	Electrolux
94406610600	EVY7800AAV	Electrolux
94406610601	EVY7800AAV	Electrolux
94406610602	EVY7800AAV	Electrolux
94406610603	EVY7800AAV	Electrolux
94406611100	EVY5841AAX	Electrolux
94406611101	EVY5841AAX	Electrolux
94406611300	EVY3841AOX	Electrolux
94406611400	EVY8840AAX	Electrolux
94406611401	EVY8840AAX	Electrolux
94406611500	EVY9841AAX	Electrolux
94406611501	EVY9841AAX	Electrolux
94406611600	EVY9841AAX	Electrolux
94406611601	EVY9841AAX	Electrolux
94406611700	EVY9841AOX	Electrolux
94406611701	EVY9841AOX	Electrolux
94406611800	EVY9841AOX	Electrolux
94406612200	KE5840402M	AEG
94406612400	KS8454801M	AEG
94406612500	EVY0841VAX	Electrolux
94406612600	EB4SL70CN	Electrolux
94406612601	EB4SL70CN	Electrolux
94406613300	JLBIC03M	John Lewis
94406613301	JLBIC03M	John Lewis

PNC	MODEL	BRAND
94406613302	JLBIC03	John Lewis
94406613700	EVY97800AX	Electrolux
94406613701	EVY97800AX	Electrolux
94406613702	EVY97800AX	Electrolux
94406613703	EVY97800AX	Electrolux
94406613900	EVYP5841AX	Electrolux
94406613901	EVYP5841AX	Electrolux
94406613902	EVYP5841AX	Electrolux
94406614000	EVYP9841AX	Electrolux
94406614002	EVYP9841AX	Electrolux
94406614200	KP8404001M	AEG
94406614201	KP8404001M	AEG
94406614300	EVYP9841AX	Electrolux
94406614400	EVYP5841AX	Electrolux
94406614600	EVYP5841AX	Electrolux
94406614700	EVYP7800AX	Electrolux
94406614701	EVYP7800AX	Electrolux
94406614702	EVYP7800AX	Electrolux
94406614800	EVYP7800AX	Electrolux
94406614900	EVYP7800AX	Electrolux
94406615200	EVK5840AAX	Electrolux
94406615201	EVK5840AAX	Electrolux
94406615300	EVK5840AOX	Electrolux
94406615500	EB4SL70SP	Electrolux
94406615501	EB4SL70SP	Electrolux
94406615600	KP8404021M	AEG
94406615700	EB4GL70SP	Electrolux
94406615800	EB4GL70CN	Electrolux
94406615900	EB4SL60SP	Electrolux
94406615901	EB4SL60SP	Electrolux
94406616000	EB4SL60CN	Electrolux
94406616001	EB4SL60CN	Electrolux
94406616100	KM5840302M	AEG
94406616102	KM5840302M	AEG
94406616300	EB4SL80SP	Electrolux
94406616301	EB4SL80SP	Electrolux
94406616400	EB4SL80CN	Electrolux
94406616401	EB4SL80CN	Electrolux
94406617100	KP8404001M	AEG
94406617101	KP8404001M	AEG
94406617200	KP8404021M	AEG
94406617201	KP8404021M	AEG
94406617300	EVK5840AAX	Electrolux

PNC	MODEL	BRAND
94406618100	LAM7000	Lamona
94406618101	LAM7000	Lamona
94406618400	EVK95840AX	Electrolux
94406618600	KM8403101M	AEG
94406618601	KM8403101M	AEG
94406618602	KM8403101M	AEG
94406618700	KM8403101M	AEG
94406618701	KM8403101M	AEG
94406618702	KM8403101M	AEG
94406618800	KR8403101M	AEG
94406618801	KR8403101M	AEG
94406618802	KR8403101M	AEG
94406618900	KR8403101M	AEG
94406618901	KR8403101M	AEG
94406618902	KR8403101M	AEG
94406619000	KE8404101M	AEG
94406619001	KE8404101M	AEG
94406619100	KE8404101M	AEG
94406619101	KE8404101M	AEG
94406619200	KE8404101M	AEG
94406619300	KT8403101M	AEG
94406619500	KS8404101M	AEG
94406619600	KS8404101M	AEG
94406619900	KM5840310M	AEG
94406619901	KM5840310M	AEG
94406619902	KM5840310M	AEG
94406620100	EVY9847AAX	Electrolux
94406620400	KS8404701M	AEG
94406621300	KULINARISK 80300957	IKEA
94406621301	KULINARISK 80300957	IKEA
94406621800	KULINARISK 30300912	IKEA
94406622000	EVY5841BAX	Electrolux
94406622100	EVY5841BAX	Electrolux
94406622300	EVY5841BOX	Electrolux
94406622400	EVY5841BOX	Electrolux
94406623100	KE8404021M	AEG
94406623600	FQM465CNE	Electrolux
94406623700	FQM465CBE	Electrolux
94406623800	FQM465CXE	Electrolux
94406623801	FQM465CXE	Electrolux
94406624200	KM8403101M	AEG
94406624201	KM8403101M	AEG

PNC	MODEL	BRAND
94406624300	KR8403101M	AEG
94406624301	KR8403101M	AEG
94406624800	KULINARISK 90307449	IKEA
94406624801	KULINARISK 90307449	IKEA
94406624900	KULINARISK 10307448	IKEA
94406625100	KS8454801M	AEG
94406625200	EVY0841BAX	Electrolux
94406625600	ID_704962	Küppersbusch
94406625601	ID_704962	Küppersbusch
94406625700	ID_704961	Küppersbusch
94406625900	KS8404701M	AEG
94406626100	EVY9847AAX	Electrolux
94406626200	EVY9847AOX	Electrolux
94406626400	KS8404721M	AEG
94406626500	KS8404721M	AEG
94406633500	KS8454801M	AEG
94406633600	KP8404001M	AEG
94406633700	KM8403101M	AEG
94406633701	KM8403101M	AEG
94406634100	KULINARISK 30322042	IKEA
94406634500	LAM7001	Lamona
94406634501	LAM7001	Lamona
94406634600	KS8404101M	AEG
94406635200	EVY7800AAX	Electrolux
94406635201	EVY7800AAX	Electrolux
94406635301	EVY6800AAX	Electrolux
94406635600	KS8404721M	AEG
94406636200	BO4SEM	AEG
94406636300	BO4MGM	AEG
94406636400	JLBIMW03	John Lewis
94406636500	JLBIC04	John Lewis
94406636501	JLBIC04	John Lewis
94406636600	EVY7810AAV	Electrolux
94406636601	EVY7810AAV	Electrolux
94406636800	KM8403111M	AEG
94406636900	KM8403101B	AEG
94406636901	KM8403101B	AEG
94406637000	KS8454801B	AEG
94406637100	KR5840310M	AEG
94406637200	EVY96800AX	Electrolux
94406637201	EVY96800AX	Electrolux

PNC	MODEL	BRAND
94406637401	EVY6800ZOZ	Electrolux
94406637500	EVY7800ZOZ	Electrolux
94406637501	EVY7800ZOZ	Electrolux

PNC	MODEL	BRAND
94406637600	KM1840310X	AEG
94406637601	KM1840310X	AEG
94406637700	KS1845480X	AEG

REVISION:

Revision	Date	Description	Author	Approved by - on
00	03/2016	Document Creation	Ewelina Fidor	Thomas Thomsen 2016-06-06