



### Exchange of not configured electronics with new ones

#### DESCRIPTION:

In hobs, old not configured electronics will be no longer available and they are not fully compatible with the new ones.

#### SOLUTION:

To mount new hardware in appliance which was equipped originally with old version of hardware, it is required to programme new hardware using new configured variant.

#### SPARE PART NUMBER:

List of new not configured electronics which are required to be ordered in case of exchange to the new ones.

old hardware	new hardware
140053758052	140053758102
140053758029	140053758078

List of new configured electronics which are required to be used during programming of the new hardware.

old variant of configured electronic	new variant of configured electronic
982140063517011	982140063517227
982140063517029	982140063517235
982140063517060	982140063517268
982140063517078	982140063517276
982140063517086	982140063517284
982140063517094	982140063517292
982140063517128	982140063517326
982140063517136	982140063517334
982140063517151	982140063517359
982140063517169	982140063517367
982140063517177	982140063517375
982140063517185	982140063517383
982140063517219	982140063517417

**MODELS INVOLVED:**

This solution is valid for models with old type of electronic boards listed in the above table.

**REVISION:**

<b>Revision</b>	<b>Date</b>	<b>Description</b>	<b>Author</b>	<b>Approved by - on</b>
00	05/2018	Document Creation	Ewelina Fidor	Katharina Baumgartner 2018-06-06