



OVENS – NOISE & VIBRATIONS DURING THE FUNCTIONING

DESCRIPTION:

In case of noise or vibrations during the functioning, it's important to check the top cover.

SOLUTION:

- To verify that the top cover is properly snapped-in at the front (green circle) and fixed by means of two screws at the back (green arrows)



- If the noise remains, to replace the top cover ordering the spare part number 140064666039
- After the replacement of the top cover, if the noise remains, to check the cooling fan assembly

SPARE PART NUMBER:

Old spare part code	New spare part code	Description
140064666013	140064666039	Top cover

QES CODE:

During the intervention please use work code 11 and:

Component	107
Defect	09

MODELS INVOLVED:

Sputnik Update Ovens equipped with Top Cover 140064666013 (till SN 902xxxxx)

REVISION:

Revision	Date	Description	Author	Approved by
00	03/2019	Document Creation	BSP	Gabriele Brandoli