

REMOVING/ASSEMBLING THE DISPLAY

DESCRIPTION:


To avoid display damages do not use any sharp objects to remove the display. Display can be easily removed with the disassembly tool.

CAUTION: The plug must be pulled out before the display is removed.



1. Place and fix the disassembly tool on to bottom side of display and pull to take out the display.
2. Take out the display cable socket.

DISASSEMBLY/ASSEMBLING TOOL:

Spare part number	Description	
4055583944	Suction cap,service,tool	

Use the tool if you need to remove/assembly display listed below.

Spare part number	Description
4055509485	Display, door
4055509147	Display, door
4055481198	Display, door
4055488094	Display, door
4055485652	Display, door
4055486320	Display, door
4055487997	Display, door
4055488086	Display, door
4055507950	Display, door

REVISION:

Revision	Date	Description	Author	Approved by - on
00	06/2021	Document Creation	Edyta Orzech	Dmytro Gavrylkiv