



# Electrolux

**ELECTROLUX HOME PRODUCTS PTY LTD**

ABN 51 004 762 341

Technical Bulletin N° CEB091

Issue: 1

Date: 11/12

## Kronos 2 Touch Control Not Responding.

**SERVICE:** If the controller is displaying but not responding when touched, before changing any part ensure the 2 x short leads are fully pushed onto their respective boards.

