

Electrolux

ELECTROLUX HOME PRODUCTS PTY LTD
ABN 51 004 762 341

Technical Publication N° DR146

Issue: 2
Date: 05/12

ELECTROLUX


CONDENSER DRYER

SECTION	PAGE N°
FUNCTIONAL ASSEMBLY	2 & 3
CABINET ASSEMBLY	4 & 5
ELECTRICAL EQUIPMENT ASSEMBLY	6 & 7
CONTROL PANEL ASSEMBLY	8 & 9
DOOR ASSEMBLY	10 & 11
BASE ASSEMBLY	12 & 13
WIRING DIAGRAM	14
CIRCUIT DIAGRAM	15

Release Date 12/09
Production moved to krakow


MODEL:

EDC47130W
PNC: 916094532 06




9163014204


Item	Part N°	Description	Qty
130	1368089106	Gasket, Front, Large Opening,	1
130B	1251102-22/2	Drum Seal, Back, Cpl.	1
130C	1258379-02/1	Seal, Bearing	1
250	1256910512	Drum, Complete, SMART(EMZII)	1
253	1258288-10/7	Drive Belt, L=1975H7	1
255A	1250134-11/9	Bearing, Back, Complete	1
262	1256522119	Drum Lifter, ENV06-TC6	3
335	1364059004	Assembly, Roll, Channel Drainage	2
514A	1254250010	Bush, Support, Roller	1
520A	1250232-06/1	Axle Complete	1
523A	1254242504	Fluff Filter, Air Intake	1
531	1240222-01/6	Screw, Fixing, Roller, NEX4	1
550	1255061077	Coat, Bolt, Basket	1
NI	1051185-00/5	Disc, 13x18X0.5	1




Item	Part N°	Description	Qty
116	1251079-03/2	Bezel,Rearpanel,NEX4CONDROHS	1
130	1257473007	Sealing, Flap, Nx4cond.	1
130A	50277852005	Kit, Back Panel seal,NX4C	1
135	1254360314	Channel Drainage, Air, Front	1
303	1256632-02/5	Plinth,White,ENV06CRM	1
308	1123347-00/5	Hinge, Base, Flap Door	1
310	1256633-02/3	Support, Door, Outer	1
310B	1123346-11/4	Support, Inner Door	1
310C	1123314104	Retainer, Pushbutton	1
310D	1123452-00/3	Push Button, Base	1
310E	1123316-01/8	Pressure Spring	1
313	1256638-02/2	Tabletop,ENV06WHITE	1
324	1364000602	Front Panel, White	1
325	1251093-22/3	Catch,Flap,Nx4aeg	1
325A	1364016004	Spring, Safety, Porthole	1
326	1364006-20/3	Side Panel, Cabinet, White	2
330	1256640-00/2	Adjustable Foot	4
334	1361031303	Assembly, Rear Ppanel,N4C	1
344	1251111-00/9	Spring Latch, Fixing, Side Panel	1
500	1251068-10/0	Knob,Lock,Tank,NX4	1
514	1254485-10/3	Bush, Knob, Catch ,T.B.	1
521	1254262-00/7	Holecover,Frontpanel,NEX4	1
523	1251075-05/5	Crossbar, Stiffening, Upper	1
523B	1254160-01/1	Bracket,Harness,NEX/4TDC	1
550A	3792679-00/7	Protection,Backpanel,Nexus/4cond.	1
555	1254261-00/9	Decorplate,Hinge,NEX4	2
563	1123311-00/1	Hinge Pin	1




Item	Part N°	Description	Qty
004	3705241176	Main Motor, STACK 35mm & 32mm	1
007	1254253-15/4	Door Lock, EMZ NX4	1
007A	1258513-16/5	Micro Switch, Water	1
10	1257530335	Heating Element,240V 1400+600W	1
11	1250020-33/4	Capacitor, Motor,8MF DUCATI	1
037	1364090611	Power cable with filter, AUS	1
048C	1242940-10/2	Sensor	1
130C	1246644-00/7	Sealing, Temperature Sensor	1
159	1254348-01/2	Fan Blade,Back,NEX4 COND.	1
159A	1254349-01/0	Fan Wheel,Front,NX4 COND	1
251	1251060-00/8	Rubber Damper, Main Motor ,Ø 49,7	1
260A	1258474-01/2	Tension Spring, Motor	1
263	1250125034	Clamping Roller	1
514	1251061-00/6	Bush, Main Motor, White	1
514A	50278238-00/6	Kit,Bush,Motor,NX4C	1
523	1251059-00/0	Fixing Bracket, Main Motor, Front	1
523A	1251058-00/2	Fixing Bracket, Main Motor, Back	1
587	973916094532066	Configured Electronic,ENV06 LOW, 25P	1
NI	1250124-01/1	Washer	1
NI	1360199010	Harness, Complete	1
NI	1258825-22/1	Power Cable, AUS	1
NI	1123555-00/3	Felt Disc, Axle, Motor	1




Item	Part N°	Description	Qty
500	1325083-01/0	Knob, Programme Selector,ENV06	1
510	1368056006	Control Panel, Silk Screened	1
525	1325085320	Push Button, Start/Pause,Silver	1
525A	1325086708	Button set,white, 2, TC5	1
525C	1325091112	Support, Push Button,TC/4/5/6	1
536	1256588-00/3	Diffuser,Env06 Tc3/Tc4/Tc5	1
563	1257385-00/3	Shaft, Selector	1



Item	Part N°	Description	Qty
120	1254246-04/2	Felt Filter, Door, NX4	1
130	1251085-02/1	Sealing, Door, NX4C	1
308	1254454-01/8	Door Hinge	2
308A	1257523009	Stiffening, Door Hinge, Plastic, NX4	2
312	1254245408	Locking Cap, Door, Internal, NX4C	1
323	1251084-04/0	Inner Frame, Door	1
323A	1251083-00/0	A-Frame, Outer Door, NEX4 COND.	1
325	1254263-04/7	Door Catch, NX4	1
555A	1254252-01/6	Decor Plate, Re-Enforcement, Door Hinge, NEX4	2
563	1254248-00/6	Pivot, Door Hinge, NEX4	1




Item	Part N°	Description	Qty
110	1123441-00/6	Discharge Pipe	1
125	56471210908	O-Ring, Ø 9,25 mm	1
125A	56471211-00/5	O-Ring, Ø 17,86 mm	1
130	1251053-00/3	Gasket,Basement,Air Duct,NEX4 COND.	1
130A	1251067-00/3	Gasket, Heat Exchanger,Front,NEX4 COND.	1
130B	1254489-00/6	Sealing, Rear Panel,NX4C	1
137	1257382-00/0	Float	1
140	1251056-00/6	Drop Tray,NEX4 COND.	1
146	1251063-16/8	Assembly, Steam Condenser	1
153	56471210-80/9	Valve, Tank	1
260	56471219-70/1	Spring, Valve, Tank	1
303	N.P.N.	Assembly, Basement, T. B.	
309	1251054-10/0	Cover, Scroll Cover, Front	1
309A	1251055-02/4	Bezel, Scroll Cover, Back	1
309B	1251069-11/6	Bezel, Sump, T.B.	1
346	1258261-11/2	Assembly,Tank,NEX4C T/B	1
500	1251068-00/1	Knob,Lock,NEX4 COND.	1
520	56471211-20/3	Valve Housing	1
520A	56471210-70/0	Flange	1
521	1258790011	Stopper, Tank	1
523	3705243-00/8	Support, Micro Switch, Float	1
557	1251057-04/6	Insulator, Scroll Cover, Back	1



IMPORTANT SAFETY NOTICE

This diagram has been prepared for use by electrically qualified service technicians. Electrolux cannot be held responsible for the interpretation of its service publications nor for any injury or damage that may occur in connection with their use.



125 670450c

IMPORTANT SAFETY NOTICE

This diagram has been prepared for use by electrically qualified service technicians. Electrolux cannot be held responsible for the interpretation of its service publications nor for any injury or damage that may occur in connection with their use.