


42





1

50



15




40




40A




40B



20




28



26

18



60

P09133005135

© Electrolux