


40E




40C




40D



15



40B




40




40A




41A




20




28



26



18



60



P09133005146

© Electrolux