




42



50



15




40




40A




40B




20



28




26



18

60



P09133006105

© Electrolux