



SPARE PARTS LIST

Gas,ceramic

(Builtin hobs, with controls)


2253

Item	PNC	ELC	Brand	Model	Market
A	943002504	00	ZANUSSI	ZGB729X	S.E.A.

		Gas,ceramic (Builtin hobs, with controls)	
Electrolux Thailand Co.,Ltd. 1910 Electrolux Building New Petchburi Rd. Bangkapi Huaykwang Bangkok , 10310 Tel : +662 725 9000			
Publication-No. 120727			

Model : ZGB729X
PNC : 943002504

Ex. View Drawing



Item	PNC	ELC	Brand	Model	Market
A	943002504	00	ZANUSSI	ZGB729X	S.E.A.

Pos.	Part No.	Description
1	HS-0300/AA	S/S TOP PLATE-ZANUSSI
2	HS-0305/AB	IGNITION VALVE (ZGB729X)
3	HS-0306/AB	INNER CAP (HSG-22)
4	HS-0306/BB	OUTER CAP (HSG-22)
5	HS-0306/CB	FRAME SPREADER (HSG-22)
6	HS-0307/AB	BURNER HEAD (HSG-22)
8	HS-0305/RA	GENERATOR 2P
9	HS-0305/XB	SPARKER (HSG-22)
10	HS-0308/AB	STAND (ENAMEL) ZGB729X
11	HS-0308/CA	WOK STAND-ENAMEL
12	HS-0302/AA	KNOB (LEFT) A296
13	HS-0302/AB	KNOB (RIGHT) A296
14	HS-0305/SA	BATTERY BOX
15	HS-0313/AC	BATTERY BOX BLOCK PLATE (HSG22)
16	HS-0313/AB	GENERATOR BLOCK PLATE
17	HS-0303/XA	AIRVENT (FIX)
18	HS-0303/XB	AIRVENT (OUTER)
19	HS-0303/XC	AIRVENT (INNER)
20	HS-0303/XZ	AIRVENT SPRING
21	HS-0305/ZB	SPARKER CLIP
22	HS-0302/BB	KNOB GASKET (ZGB729X)
23	HS-0301/AA	RUBBER LEG
24	HS-0304/AA	IRON PIPE
25	HS-0311/AA	TOP PLATE SUPPORT (FRONT)
26	HS-0311/AB	TOP PLATE SUPPORT (BACK)
27	HS-0310/AC	BOTTOM PLATE (ZGB729X)