

A	FSR 02622	WHE

(E) Earth cabinet
(G) Fan
(F) Flexible cord
(L1) 230V Lamp
(K) Compressor FRZ
(H) Starting device
(C) Run capacitor
(L2) 12V halogen lamp
(I) Lamp switch halogen lamp

208 38 32-00

Variant No.

Spec. 124, 141, 109

TITLE

Wiring diagram

DESIGN OWNER	DRN	CHD	DATE
MA	WHE	APPR.	021101

Kopplingsschema

Electrolux

NUMBER

208 38 32

REV.

A