

This drawing contains confidential information and is the property of Electrolux, without whose permission it may not be copied, shown or handed to a third party or otherwise used for any purpose not expressly agreed upon request to the design owner, who is responsible for the drawing.

Items shown in this drawing must not contain substances that are banned according to Directive, 2002/95/EC, the RoHS Directive (Lead, Cadmium, Mercury, hexavalent Chromium, PBB and PBDE), or substances classified as "Banned" or "Restricted" according to the Electrolux Restricted Materials list.

GENERAL TOLERANCES
ANGLES
LENGTHS AND DIAMETERS

Earth connection energy regulators

See hob assembly

Thermostat

POS	No	Note
29	1	Wireset MP timer
28	-	
27	1	Capacitor oven lamp 25W
26	1	Capacitor oven lamp 40W
25	1	WIRESET DOORSWITCH hot air element
24	1	WIRESET DOORSWITCH LIGHT
23		
22		
21	1	Main switch/ oven function
20	1	THERMOSTAT
19	1	MEATPROPE DISPLAY
18	1	Wireset MP socket
17	1	JACK SOCKET
16	1	TERMINAL STRIP 6 POLS, SNAP
15	1	OVENLAMP TOP
14	1	Oven lamp side
13	1	THERMOSTATLAMP
12	1	FAN MOTOR HOT AIR OVEN
11	1	COOLING FAN
10		
9	2	MICROSWITCH FAN/LIGHT
8		
7	1	THERMAL CUT OUT
6		
5	-	
4	-	
3	1	HEATINGELE. HOTAIR 2400W
2	1	HEATINGELE. TOP 1000/1900W
1	1	HEATINGELE. LOWER 1000W

ID	DESCRIPTION	ELUX PART NO.
24	Wire door switch	349 5325-01
25	Wire door switch	349 4194-01
21	Oven selector wiring	349 4179
▶	INSULATION HOUSING	
	LIST OF CRIMP CONTACTS	330 1766
	Component list	330 2222

VARIANT NUMBER	REPLACED NUMBER	POS.	MODEL	DESIGN USERS	CHANGES FROM THE BASE NUMBER
349 5660-02			400V	-	

POS.	MODIFICATIONS	SIGNATURE	REQUEST	DATE
A	First edition	S.Ahl	ABS 5439	2007-06-18

MATERIAL
TREATMENT
WEIGHT
DESIGN OWNER -
DRN S.Ahl
DATE 2007-06-18
CHD S.Ahl
APPR S.Ahl
MODEL
DESIGN USERS
SCALE
REPLACES
DERIVED FROM
SUPPLY SPECIFICATIONS
EUROPEAN METHOD
TITLE Wiring oven assembly
NUMBER 349 5660
REV A
SHEET

Electrolux

A2 [DP03]