
NOT INCLUDED IN THE ASSEMBLY
132 5244 0/
132 5230 1/
LCD full graphic
External full graphic board
EWM 3500
J15
J16
J13
J12
J11
J10
J9
J8
J18
J4
J5
J14
J3
J2
J1
U3
J15 – bis
Drum Light
132 4376 0/
NOT INCLUDED IN THE ASSEMBLY
132 5231 0/
Door safety interlock (istantaneous)
132 5225 5/
Prewash valve
Wash valve
Analogic pressure level
132 5229 2/
Recirculation pump version
132 5425 1/
Flow sensor
132 5233 0/
132 5424 1/
Drain pump
General earth
Anti interference filter
132 5240 2/
Heating element
132 5226 2/
Temperature probe
132 5237 0/
132 5238 0/
FVC programmer connector
J13 – bis
J18
Aqua Control
External motor control board
Motor connector
132 5221 0/
132 5239 0/
Tub earth
Cim motor
132 5222 0/
Motor endshield
NOT INCLUDED IN THE ASSEMBLY