
NOT INCLUDED IN THE ASSEMBLY
132 5230 0/
EWM 2100
Door safety interlock (Traditional version)
LCD
J15
J16
J13
J12
J11
J10
J9
J8
J7
J5
J14
J15-bis
J1
J2
J3
NOT INCLUDED IN THE ASSEMBLY
132 5235 0/
132 5231 0/
Door safety interlock (traditional)
Door safety interlock (istantaneous)
132 5225 9/
Prewash valve
Wash valve
Remote Display Board
132 4404 0/
Analogic pressure level
132 5229 6/
132 5228 4/
General earth
Drain pump
Anti interference filter
NOT INCLUDED IN THE ASSEMBLY
132 5221 0/
Motor
Heating element
132 5224 4/
Motor earth
Temperature probe
132 5220 6/
132 5226 5/