
29
74
84
84
ELECTROLUX CODE FOR RIGHT BOARD PRINTED ON ORANGE LABEL
(****) PARTICULAR JUMPER CONNECTION ONLY ON LEFT BOARD
JUMPER
BC1
BC5
EARTH HOB
86
87
SENSOR
EARTH SENSOR
70
THERMOSTAT D.LOCK
52
57
54
77
34
20
32
31
COOLING RESISTOR 800 Ω
84
DOOR LOCK
OVC 1000 POWER BOARD
CONNECTOR BLACK 4POLES
CONNECTOR WHITE 6POLES
CONNECTOR WHITE 4POLES
GRILL
BOTTOM
TOP
RING
71
LIMIT
DISPLAY BOARD KRONOS
BA1
86
107
MOTOR
SWITCH MOTOR
DOOR SWITCH

357 435301b