
X1 / 2 (L2)
X1 / 1 (L1)
User Interface
FALCON/KITE
XC01
BR10
BR11
BR04
BR05
BB01
N1
EVEREST
powerboard
KR06
KR07
KR08
KR05
KR10
KR01
KR02
KR03
KR04
KR09
BR08
BR09
BR12
BR07
BR17
BR18
BR19
BR20
BR01
BR02
BR03
BR06
BR13
BR14
BR15
BR16
1
4
3
r31
2
4
r32
2
4
4a
r33
2
4
r32
2
Cooking Zone
Left Fronf
Cooking Zone
Left Rear
Cooking Zone
Right Rear
Cooking Zone
Right Fronf
X1 / 4 (N)
X1 / PE
PE

561772900