125 713011b


ONLY IN VERSION WITH LCD
(HIGH)
ENV06 DRYER
LCD
J3
J5
J4
J2
J1
J10
J9
J6
J13
J8
J7
J12
Jx
J3-bis
Drum sensor
CRM Board
J1
J8
J9
J6
J12
J11
J7
J2
J4
J3
J5
J flash
Door switch
2nd Door switch
NOT INCLUDED IN THE ASSEMBLY
Drum lamp
STEAMER
Temperature probe
Level switch
Pump
Junction box + Anti-interference filter
Motor
Motor capacitor
Heating element
Steamer switch