

© ELECTROLUX ITALY S.p.A.
Spares Operation Europe
Corso Lino Zanussi, 30

I - 33080 PORCIA/PN (ITALY)

Fax +39 0434 394096

Edition: 01-2011

Publication
number

599 73 77-37

EN

Washing machines

**guide to diagnostics of
electronic controls**

EWM10931

Contents

1	INTRODUCTION.....	5
1.1	Purpose of this manual.....	5
1.2	Warnings.....	5
1.3	How to proceed.....	5
2	WM APPLIANCE CONTROL PANELS.....	6
3	DIAGNOSTIC SYSTEM.....	7
3.1	Accessing diagnostics.....	7
3.2	Quitting the diagnostics system.....	7
3.3	Diagnostic test phases.....	8
4	ALARMS.....	10
4.1	Displaying the alarms to the user.....	10
4.2	Reading the alarms.....	11
4.3	Rapid reading of alarms.....	12
4.4	Deleting the last alarm.....	12
5	OPERATING TIME COUNTER.....	13
5.1	Reading the operating time.....	13
5.2	Display of total operating time.....	13
5.3	ALARM SUMMARY TABLE.....	14
5.4	Notes on the behaviour of certain alarms.....	18
6	CANNOT ACCESS THE DIAGNOSTICS PROGRAMME.....	19
6.1	None of the LEDs on the circuit board light up.....	19
6.2	Some LEDs come on, on the display board.....	19
7	TROUBLESHOOTING BASED ON ALARM CODES.....	20
	E11: Water fill difficulty during washing.....	20
	E13: Water leaks.....	22
	E21: Drain difficulty.....	24
	E23: Problems with the component (triac) controlling the drain pump.....	26
	E24: "Sensing" circuit of the component (triac) controlling the drain pump faulty.....	28
	E32: The analogue pressure switch causes an error during calibration.....	29
	E35: Water level too high.....	30
	E38: Internal pressure chamber is clogged.....	31
	E41: Door open (device with 4 connections).....	32
	E42: Problems opening door (device with 4 connections).....	34
	E43: Problems with the component (triac) controlling the door delay system (device with 4 connections).....	36
	E44: Door closed "sensing" circuit faulty.....	37
	E45: Problems with the "sensing" circuit of the component (triac) controlling the door delay system.....	37
	E52: No signal from motor tachometric generator (<i>first part</i>).....	38
	E52: No signal from motor tachometric generator (<i>second part</i>).....	40
	E57: Inverter is drawing more than 16A current.....	42
	E58: Inverter is drawing more than 4A current.....	44
	E59: No signal from the tachometric generator.....	46
	E5A: Overheating on Inverter board heat dissipator.....	48
	E5C: The Inverter board input voltage is too high (beyond 430V).....	49
	E5d: Data transfer error between Inverter board and main circuit board.....	50
	E5E: Communication error between Inverter board and main circuit board.....	51
	E5F: Inverter board fails to start the motor.....	51
	E5H: The Inverter board input voltage is too low (less than 175V).....	52
	E62: Overheating during washing.....	53
	E66: Heating element power supply relay faulty.....	54
	E68: Washing heating element leakage.....	55
	E69: Washing heating element damaged.....	56
	E6A: Heating relay "sensing" faulty.....	57
	E6H: Heating element power relay faulty (incongruence between "sensing" and relay status).....	57
	E71: Washing NTC probe faulty.....	58
	E74: NTC probe improperly positioned.....	59
	E83: Error reading the programme selector code.....	60
	E86: Programme selector configuration error.....	60
	E87: User Interface microcontroller defective.....	60
	E91: Communication error between the display board and the main circuit board.....	61
	E92: protocol incongruence.....	62
	E93: Appliance configuration error.....	62

E94: Incorrect configuration of washing cycle	62
E97: Inconsistency between control selector version and configuration data.....	62
E98: Communication error between main PCB and Inverter board	62
E9C: Display board configuration error.....	63
E9E: Display board sensor/touch key faulty.....	63
EC1: Water fill solenoid valves blocked	64
EC2: Problem with weight sensor.....	65
EC3: Problem with weight sensor.....	66
EF1: Drain hose blocked/kinked/too high; drain filter clogged/dirty.....	67
EF2: Excessive detergent dosing; drain hose kinked/blocked; drain filter dirty/clogged	67
EF3: Aqua Control device triggered.....	67
EF4: Water fill pressure too low and solenoid valve open	67
EF5: Unbalanced load, spin phases skipped.	67
EF6: Reset appliance.....	68
EH1: Mains frequency incorrect.....	68
EH2: Supply voltage too high	68
EH3: Supply voltage too low.....	69
EH4: "zero watt" relay not functioning.....	69
EHE: Inconsistency between safety relay (main circuit board) and safety "sensing" circuit	69
EHF: Safety "sensing" circuit faulty.....	69
8 WM OPERATING CIRCUIT DIAGRAM.....	70
8.1 Key to circuit diagram WM.....	71
8.2 Main circuit board connectors	72
8.3 Burns on the main circuit board EWM10931	73

1 INTRODUCTION

1.1 Purpose of this manual

The purpose of this manual is to explain, simply and schematically, the steps any Technician should take when faced with the problems indicated by the various alarm codes on appliances with electronic control in the EWM10931 series, NEW COLLECTION SERIES 7/8/9 version.

Depending on the appliance configuration, the alarms may be entirely or partially displayed to the user: the latter solution is usually adopted.

The diagnostics system is used by Service Technicians to:

- ◆ Read alarms
- ◆ Delete the alarm stored
- ◆ Test the appliance operation

1.2 Warnings



- **Any work on electrical appliances must only be carried out by qualified technicians.**
- **The selector on this platform is not fitted with an ON/OFF switch. Before you access internal components, take the plug out of the socket to cut the power supply.**
- **If the heating element needs replacing, replace it with one featuring the same characteristics (2 thermal fuses) so as not to compromise the safety of the appliance. It is strictly forbidden to remove/exchange the NTC probes from one heating element to another.**
- **Always empty the appliance of all the water before laying it on its side.**
- **Never place the appliance on its right side (electronic control system side): some of the water in the detergent dispenser could leak onto the electrical/electronic components and cause these to burn.**
- **When replacing components, please refer to the code shown in the list of spare parts relating to the appliance.**



1.3 How to proceed

1. Identify the type of control in question (**page 6**) and access the diagnostic cycle (**See page 7**)
2. Read the alarm stored (**page 11**) and consult the instructions regarding the “alarm codes”, **page 14÷17**.
3. Delete the alarms stored (**Page 12**)
4. If you are unable to access the diagnosis mode, consult the chapter entitled “The diagnostics system cannot be accessed” (**page 19**)
5. Should the main electronic circuit board need to be replaced, make sure there are no burns (**See page 73**)
6. After all intervention, check the appliance is operating correctly using the diagnostic cycle (**page 8**)
7. Delete any alarm that may have been stored during the diagnostics operations (**page 12**)

2 WM APPLIANCE CONTROL PANELS




These are the stylings available at the time of printing of this Service Manual. Others may be developed in future.

NEW COLLECTION	SERIES 7	
	SERIES 8	
	SERIES 9	

3 DIAGNOSTIC SYSTEM

3.1 Accessing diagnostics

All versions








SERIES 7	SERIES 8	SERIES 9
		
<p style="text-align: center;"><u>Do not start the procedure with the combination buttons pressed</u></p> <ol style="list-style-type: none"> 1. Turn the appliance on at the ON/OFF switch and the first LED in the right-hand row turns on. 2. Press the START/PAUSE button and the nearest option button simultaneously (as shown in the figure). 3. Hold the buttons/sensors down/pressed until the LEDs and symbols begin to flash in sequence (approximately 3 seconds). <p>In the first position, the operation of the buttons, of the related LEDs and of the groups of symbols shown on the LCD screen is checked; turn the programme selector dial clockwise to run the diagnostic cycle for the operation of the various components and to read any alarms (see diagnostic testing on the following page). During this phase, if any key combination is pressed (except for the one relating to diagnostics), all the combinations of options stored are deleted (Extra rinse, No buzzer, etc..) whereas for SERIES 9, the memories with the customised programmes are also deleted</p>		









3.2 Quitting the diagnostics system

→ To quit the diagnostics system, turn the selector dial to position 0, turn the appliance back on and return the dial to position 0.

3.3 Diagnostic test phases

Irrespective of the type of electronic board and of the selector configuration, once the diagnostics system has been activated, turn the selector dial **clockwise** to run a check of the various components and read the alarms. Concurrently, a selector control code is shown on the LCD display, which indicates for **two** seconds the description in the last column of the table below. (all alarms are enabled in the diagnostic cycle).

TABLE 1					
Selector position	Components activated	Working conditions	Function tested	LCD display	
1	<ul style="list-style-type: none"> - The LEDs, groups of symbols in the LCD screen and the backlight of the display are turned on in sequence - Press a button/sensor to turn on the group of icons in the LCD screen or the corresponding LED and the buzzer sounds at the same time 	Always active	User interface functions		
2	<ul style="list-style-type: none"> - Door safety interlock - Wash solenoid 	Door closed Water level below anti-flooding level Maximum time 5 mins	Water fill to wash compartment	 Water level in the tub (mm)	
3	<ul style="list-style-type: none"> - Door safety interlock - Pre-wash solenoid 	Door closed Water level below anti-flooding level Maximum time 5 mins	Water fill directly to tub	 Water level in the tub (mm)	
4	<ul style="list-style-type: none"> - Door safety interlock - Solenoid valve pre-wash and wash 	Door closed Water level below anti-flooding level Maximum time 5 mins	Water fill to conditioner compartment	 Water level in the tub (mm)	
5	<ul style="list-style-type: none"> - Door safety interlock - Third solenoid valve 	Door closed Water level below anti-flooding level Maximum time 5 mins	Water fill to third solenoid valve compartment	 Water level in the tub is displayed (mm)	
6	<ul style="list-style-type: none"> - Door safety interlock - Fourth solenoid valve (hot water where featured) 	Door closed Water level below anti-flooding level Maximum time 5 mins	Water fill to fourth solenoid valve compartment	 Water level in the tub is displayed (mm)	
7	<ul style="list-style-type: none"> - Door safety interlock - Wash solenoid, if the water in the tub is not enough to cover the heating element - Heating element - Weight sensor (an extra litre of water is filled if featured) 	Door closed Water level above the heating element. Maximum time 10 mins or up to 90 °C (*)	Heating	 Temperature in °C measured using the NTC probe	

8		<ul style="list-style-type: none"> - Door safety interlock - Wash solenoid if the water level in the tub does not cover the heating element - Motor (55 rpm clockwise, 55 rpm anticlockwise, pulse at 250 rpm) 	Door closed Water level above the heating element	Check for leaks from the tub	 Drum speed in rpm/10
9		<ul style="list-style-type: none"> - Door safety interlock - Drain pump - Motor up to 650 rpm then at maximum spin speed (**) 	Door closed Water level lower than anti-boiling level for spinning	Drain, calibration of analogue pressure switch and spin	 Drum speed in rpm/10
10	-----	-----	----	---	
11		Reading/Deleting the last alarm	-----	-----	
12 ÷ 16		<ul style="list-style-type: none"> - The LEDs, groups of symbols in the LCD screen and the backlight of the display are turned on in sequence - Press a button/sensor to turn on the group of icons in the LCD screen or the corresponding LED and the buzzer sounds at the same time 	Always active	User interface functions	


(*) In most cases, this time is sufficient to check the heating. However, the time can be increased by repeating the phase without draining the water: pass for a moment to a different phase of the diagnostic cycle and then back to the heating control phase (if the temperature is higher than 80 °C, heating does not take place).

(**) The check at the maximum speed occurs without control of the AGS and no garments must be inside the appliance.

4 ALARMS

4.1 Displaying the alarms to the user

When a problem arises in the appliance, a "WARNING" or an "ALARM" is displayed with three digits, where the time until the end of the cycle is represented.



The alarms displayed to the user are listed below:

- ↵ **E10 - Water fill difficulty (tap closed)**
- ↵ **E20 - Drain difficulty (filter dirty)**
- ↵ **E40 - Door open**

The alarms listed below:

- ↵ **EF0 – Water leakage (Aqua Control System)**
For its solution, the intervention of a Service engineer is required

While for the alarm:

- ↵ **EH0 – Voltage or frequency outside the normal values**

It is necessary to wait for power supply voltage and/or frequency to restore normal conditions.

The alarms are enabled during the execution of the washing programme. With the exception of alarms associated with the configuration and the power supply voltage/frequency, which are also displayed during the programme selection phase.

The door can normally be opened (except where specified) when an alarm condition has occurred, on condition that:

- The level of the water in the tub is below a certain level.
- The water temperature is lower than 55 °C.
- The motor has stopped.



Certain alarm conditions require a drain phase to be performed before the door can be opened for safety reasons:

- Cooling water fill if the temperature is higher than 65 °C
- Drain until the analogue pressure switch is on empty, during a max. 3-minute time.

4.2 Reading the alarms

The last three alarms stored in the FLASH memory of the PCB can be displayed:

- Enter the diagnostic mode (para. 3.1)
- Irrespective of the type of PCB and configuration, turn the programme selector knob **clockwise** to the **eleventh position** the last alarm is displayed.
- To display previous alarms, press/touch the button/sensor to the left of the START/PAUSE button in sequence (as shown in the figure)
- To return to the last alarm, press/touch the START/PAUSE button/sensor.



4.3 Rapid reading of alarms

The last alarm can even be displayed if the selector is not in the tenth diagnostic position or if the appliance is in normal operating mode (for example when performing a wash programme):

→ Press the **START/PAUSE** button and the nearest **option button** simultaneously (as if you were entering DIAGNOSTIC mode) for at least 2 seconds: the LCD display shows the last alarm.




→ The alarm continues to be displayed until a button is pressed.

→ During the time that the alarm is displayed, the appliance continues to perform the cycle or, if you are in the programme selection phase, it retains the options selected previously in memory.

4.4 Deleting the last alarm

It is good practice to cancel the alarms stored:

- After reading the alarm codes, to check whether the alarm re-occurs during the diagnostic cycle
- After repairing the appliance, to check whether it re-occurs during testing

Series 7	Series 8	Series 9
		
<ol style="list-style-type: none"> 1. Enter the diagnostic mode. 2. Turn the selector dial clockwise until the eleventh LED is turned on (in the left-hand alarm reading row). 3. Press/touch the START/PAUSE button/sensor and the nearest option button/sensor simultaneously (as shown in the figure). 4. Hold down the buttons until the LCD display shows "E00" (at least 5 seconds). 		

N.B. With this operation all the alarms stored are deleted.


5 OPERATING TIME COUNTER

Using a specific procedure, the operator can display the total operating time for the appliance, which is counted from the moment it is first switched on.

The unit can count up to a maximum of **6,550** hours of operating time.

- Only the operating time of normal programmes (and not diagnostic cycles) is counted
- The actual operating time for the cycle is counted (which does not include pauses, delayed start time, rinse hold time and soaking phases)
- The precision of the counter is 30 seconds per programme
- Only whole hours of operation are counted (1hr and 59 min = 1hr)

5.1 Reading the operating time



Do not start the procedure with the combination buttons pressed

1. Turn the appliance on at the ON/OFF switch.
2. Turn the selector dial clockwise until the **fifth** LED in the right-hand row is on.
3. Press the **START/PAUSE** button and the nearest **option button** simultaneously (as shown in the figure).
4. Hold down the buttons until the hours of operation appear on the display (at least 5 seconds).

5.2 Display of total operating time

This time is displayed with a sequence of two digits at a time: the first two digits indicate thousands and hundreds, the second two digits indicate tens and units for the SERIES 7 and 8, while the time is displayed in a single sequence for SERIES 9.

For example, if the operating time is **6,550** hours, the display will show the following sequence:

	Phase 1	Phase 2	Phase 3
	For <u>two seconds</u> , the following is displayed: Hr	For <u>two seconds</u> , the following digits are displayed: ↙ thousands (6) ↘ hundreds (5)	For the next <u>two seconds</u> the following digits are displayed: ↙ tens (5) ↘ units (0)
<u>SERIES</u> <u>7/8</u>			
<u>SERIES</u> <u>9</u>	Phase 1 		Phase 2

At the end of phase three (after the tens and units are displayed), the cycle is repeated.

To return to normal mode, either: switch the appliance off or press a button or turn the selector knob.

5.3 ALARM SUMMARY TABLE

Alarm	Description	Possible fault	Machine status/action	Reset	Page
E00					
E11	Water fill difficulty during washing	Tap closed or water pressure too low; Drain pipe improperly positioned; Water fill solenoid valve faulty; Leaks from water circuit on pressure switch; Pressure switch faulty; Wiring faulty; Main PCB faulty.	Cycle is paused with door locked	START/RESET	20
E13	Water leaks	Drain pipe improperly positioned; Water pressure too low; Water fill solenoid valve faulty; Water circuit on pressure switch is leaking/clogged; Pressure switch faulty.	Cycle is paused with door locked	START/RESET	22
E21	Drain difficulty during washing	Drain pipe kinked/clogged/improperly positioned; Drain filter clogged/dirty; Wiring faulty; Pressure switch faulty; Drain pump rotor blocked; Drain pump faulty; Main PCB faulty.	Cycle paused (after 2 attempts)	START ON/OFF RESET	24
E23	Faulty triac for drain pump	Wiring faulty; Drain pump faulty; Main PCB faulty.	Safety drain cycle - Cycle stops with door open.	RESET	26
E24	Malfunction in "Sensing" circuit on triac for drain pump	Main circuit board faulty.	Safety drain cycle - Cycle stops with door unlocked	RESET	28
E31	Malfunction in electronic pressure switch circuit	Wiring; Electronic pressure switch; Main PCB.	Cycle stops with door locked	RESET	28
E32	Calibration error of the electronic pressure switch	Drain pipe kinked/clogged/improperly positioned; Solenoid valve faulty; Drain filter clogged/dirty; Drain pump faulty; Leaks from pressure switch hydraulic circuit; Pressure switch faulty; Wiring; main PCB.	Cycle paused	START/RESET	29
E35	Overflow	Water fill solenoid valve faulty; Leaks from water circuit on pressure switch; Wiring faulty; Pressure switch faulty; Main PCB faulty.	Cycle interrupted. Safety drain cycle. Drain pump continues to operate (5 min. on, then 5 min. off. etc.)	RESET	30
E38	Internal pressure chamber is clogged (water level does not change for at least 30 sec. of drum rotation)	Motor belt broken; Water circuit on pressure switch clogged.	Heating phase is skipped	RESET	31
E41	Door open	Check whether the door is closed properly; Wiring faulty; Door safety interlock faulty; Main circuit board faulty.	Cycle paused	START/RESET	32
E42	Problems with door lock	Wiring faulty; Door safety interlock faulty; Electrical current leak between heating element and ground; Main PCB faulty.	Cycle paused	START/RESET	34
E43	Faulty triac supplying power to door delay system	Wiring faulty; Door safety interlock faulty; Main circuit board faulty.	(Safety drain cycle) Cycle blocked	RESET	36
E44	Faulty sensing by door delay system	Main circuit board faulty.	(Safety drain cycle) Cycle blocked	RESET	37

Alarm	Description	Possible fault	Machine status/action	Reset	Page
E45	Faulty "Sensing" by door delay system triac	Main circuit board faulty.	(Safety drain cycle) Cycle blocked	RESET	37
E52	No signal from motor tachometric generator	Wiring faulty; Motor faulty; Inverter board faulty.	Cycle stops with door locked (after 5 attempts)	ON/OFF RESET	38/40
E57	Inverter is drawing too much current (>15 A)	Wiring faulty on inverter for motor; Inverter PCB faulty; Motor faulty.	Cycle stops with door locked (after 5 attempts)	ON/OFF RESET	42
E58	Inverter is drawing too much current (>4.5 A)	Motor malfunction (overload); Wiring faulty on inverter faulty; Motor faulty; Inverter PCB faulty.	Cycle stops with door locked (after 5 attempts)	ON/OFF RESET	44
E59	No signal from tachometric generator for 3 seconds	Wiring faulty on inverter for motor; Inverter PCB faulty; Motor faulty.	Cycle stops with door locked (after 5 attempts)	ON/OFF RESET	46
E5A	Overheating on heat dissipator for Inverter	Overheating caused by continuous operation or ambient conditions (let appliance cool down); Inverter PCB faulty. NTC open (on the Inverter PCB).	Cycle stops with door locked (after 5 attempts)	ON/OFF RESET	48
E5C	Input voltage is too high	Input voltage is too high (measure the grid voltage); Inverter PCB faulty.	Cycle stops with door locked (after 5 attempts)	ON/OFF RESET	49
E5d	Data transfer error between Inverter and main PCB	Line interference; Wiring faulty; Faulty main PCB or Inverter PCB.	-----	ON/OFF RESET	50
E5E	Communication error between Inverter and main PCB	Faulty wiring between main PCB and inverter PCB; Inverter PCB faulty; Main PCB faulty.	Cycle blocked (after 5 attempts)	ON/OFF RESET	51
E5F	Inverter PCB fails to start the motor	Wiring faulty; Inverter PCB faulty; Main PCB faulty.	Cycle stops with door open (after 5 attempts)	ON/OFF RESET	51
E5H	Input voltage is lower than 175 V	Wiring faulty; Inverter PCB faulty.	Cycle stops with door locked (after 5 attempts)	ON/OFF RESET	52
E62	Overheating during washing (temperature higher than 88 °C for more than 5 min.)	Wiring faulty; NTC probe for wash cycle faulty; Heating element faulty; Main PCB faulty.	Safety drain cycle Cycle stops with door open	RESET	53
E66	Heating element power relay faulty (inconsistency between sensing and relay status)	Main PCB faulty.	Safety water fill Cycle stops with door closed	ON/OFF RESET	54
E68	Current leak to the ground	Earth leakage between heating element and earth.	The heating phase is skipped	START/RESET	55
E69	Heating element interrupted	Wiring faulty; Heating element for washing interrupted (thermal fuse open); Main PCB faulty.	-----	START ON/OFF RESET	56
E6A	Heating relay sensing faulty	Main circuit board faulty.	Cycle stops with door locked	RESET	57
E6H	Heating element power relay faulty (inconsistency between sensing and relay status)	Wiring faulty; Earth-leakage between heating element and earth; Main PCB faulty.	Safety water fill Cycle stops with door closed	ON/OFF RESET	57
E71	NTC probe for wash cycle faulty (short-circuited or open)	Wiring faulty; NTC probe for wash cycle faulty; Main circuit board faulty.	The heating phase is skipped	START/RESET	58

Alarm	Description	Possible fault	Machine status/action	Reset	Page
E74	NTC probe for wash cycle improperly positioned	Wiring faulty; NTC probe for wash cycle improperly positioned; NTC probe faulty; Main PCB faulty.	The heating phase is skipped	RESET	59
E83	Error in reading selector	Main PCB faulty (Incorrect configuration data).	Cycle cancelled	START/RESET	60
E86	Selector configuration error	Display board.	-----	START ON/OFF RESET	60
E87	User Interface microcontroller defective	Display board	No action to be taken	START ON/OFF RESET	60
E91	Communication error between main PCB and display	Wiring faulty; Control/display PCB faulty Main circuit board faulty.	-----	RESET	61
E92	Communication inconsistency between main PCB and display (incompatible versions)	Incorrect control/display PCB; Incorrect PCB (does not correspond to the model).	Cycle blocked	ON/OFF	62
E93	Appliance configuration error	Main PCB faulty (incorrect configuration data).	Cycle blocked	ON/OFF	62
E94	Incorrect configuration of washing cycle	Main PCB faulty (incorrect configuration data).	Cycle blocked	ON/OFF	62
E97	Inconsistency between programme selector and cycle configuration	Main PCB faulty (incorrect configuration data).	Cycle blocked	RESET	62
E98	Communication error between main PCB - Inverter	Incompatibility between main PCB and Inverter.	Cycle blocked	ON/OFF	62
E9C	Display board configuration error	Display board faulty.	-----	START ON/OFF RESET	63
E9E	Display board sensor/touch key faulty	Display board faulty.	-----	ON/OFF	63
EC1	Electronically controlled valve blocked with operating flowmeter	Wiring faulty; Solenoid valve faulty/blocked, Main PCB faulty.	Cycle stops with door locked Drain pump continues to operate (5 min. on, then 5 min. off, etc.)	RESET	64
EC2	Data transfer error between Weight sensor and main PCB	Wiring faulty; Weight sensor faulty, PCB faulty.	No action to be taken	START/RESET	65
EC3	Problems with weight sensor (no signal or outside the limits)	Wiring faulty; Weight sensor faulty; Main PCB faulty.	-----	START/RESET	66
EF1	Drain filter clogged (drain phase too long)	Drain filter clogged/dirty. Drain hose blocked/kinked/too high.	Warning displayed at the end of cycle.	START/RESET	67
EF2	Overdosing of detergent (too much foam during drain phases)	Excessive detergent dosing; Drain hose kinked/blocked. Drain filter clogged/dirty.	Warning displayed after 5 attempts or by the specific LED	RESET	67
EF3	Aqua control system intervention	Water leaks onto base frame; Aqua control system faulty.	Appliance drains	ON/OFF RESET	67

Alarm	Description	Possible fault	Machine status/action	Reset	Page
EF4	Water fill pressure too low, no signal from flowmeter and electronically controlled valve is open	Tap closed, water fill pressure too low.	-----	RESET	67
EF5	Unbalanced load	Final spin phases skipped.	-----	START/RESET	67
EF6	Reset	If it continues, replace the main board.	No action to be taken	-----	68
EH1	Supply frequency of appliance outside the limits	Problem with the power supply network (incorrect/disturbed); Main PCB faulty.	Wait for nominal frequency conditions	ON/OFF	68
EH2	Supply voltage too high	Problem with the power supply network (incorrect/disturbed); Main PCB faulty.	Wait for nominal voltage conditions	ON/OFF	68
EH3	Supply voltage too low	Problem with the power supply network (incorrect/disturbed); Main PCB faulty.	Wait for nominal voltage conditions	ON/OFF	69
EH4	0Watt relay malfunction	Main circuit board faulty.	-----	ON/OFF RESET	69
EHE	Inconsistency between FCV relay (in the main board) and safety "sensing" circuit	Faulty cabling; Main circuit board faulty.	Safety drain cycle Cycle stops with door open	RESET	69
EHF	Safety sensing circuit faulty (wrong input voltage to microprocessor)	Main circuit board faulty.	Safety drain cycle Cycle stops with door open	RESET	69


5.4 Notes on the behaviour of certain alarms

- **Configuration alarm E93:** when this alarm is detected (on switching on the appliance), the appliance stops, the LEDs in the START/PAUSE button start to flash, displaying the complete code (family plus alarm), the display shows the alarm code provided the relevant configuration part is intact. It will not be possible to access diagnostics mode and the only available option is to turn the appliance off.
- **Configuration alarm E94:** the LEDs in the START/PAUSE button start to flash, displaying the complete code (family plus alarm) and the code is also shown on the display. The diagnostics mode cannot be accessed and the “quick alarm viewing” mode cannot be used.
- **Alarms EH1-EH2-EH3:** in the event of problems with the supply voltage, the appliance remains in alarm status until the mains frequency or voltage returns to acceptable values or the appliance is switched off (programme selector set to “0”). Only the family of the alarm “H” is displayed if the problem occurs during normal appliance operation. The family plus the alarm are displayed if the problem occurs when the appliance is switched on. The LEDs in the START/PAUSE button flash and the code is concurrently shown on the display. The diagnostics mode cannot be accessed and the “quick alarm viewing” mode cannot be used: the alarm can only be read in full when the situation has normalised.
- **Alarms E51- E52:** all the alarms are displayed during diagnostic testing: normally, when shifting from one control phase to another, the appliance quits the alarm mode and executes the selected phase. This is not the case for alarms E51 (motor power supply TRIAC short-circuiting) and E52 (no signal from motor tachometric generator): the only choice to quit the alarm mode is to turn the programme selector to position “0” (reset).

6 CANNOT ACCESS THE DIAGNOSTICS PROGRAMME

6.1 None of the LEDs on the circuit board light up

Are the power supply cable and the connection on the main board (connector J1) working properly?	No →	Replace/repair the power supply cable, check the connection
Yes ↓		
Is the communication wiring between the main board (connector J4) and the display board (connectors J2 and J3) working properly? (insert and remove)	No →	Replace/repair wiring
Yes ↓		
Does the ON/OFF button function mechanically?	No →	Replace/repair the button or replace the display board
Yes ↓		
Change the main circuit board Is the appliance working correctly?	No →	Replace display board
Yes ↓		
Run the diagnostics programme.		



6.2 Some LEDs come on, on the display board



Are the keys unobstructed through the control panel slots and do they activate the various buttons correctly?	No →	Sort out any mechanical problems (control panel/buttons/pins)
Yes ↓		
Change the display board and run the diagnostics programme		

7 TROUBLESHOOTING BASED ON ALARM CODES




E11	E11: Water fill difficulty during washing	E11
	Maximum water fill time for every level of the pressure switch (the time is reset every time the level is achieved)	




Run the diagnostic cycle and fill all the trays with water (**phases 2,3,4,5,6**)
Are all the trays filling with water?



E11





! If there are burns on the circuit board, see page 73






E13	E13: Water leaks	E13
	Maximum overall water fill time exceeded (sum of all water fills between one drain phase and the next to avoid exceeding the maximum volume)	


Checks to perform:



E13





! If there are burns on the circuit board, see page 73



E21	E21: Drain difficulty	E21
	Maximum drain time exceeded (measured for every cycle phase)	

Checks to perform:



E21




Fig. 1




Fig. 4







Fig. 5



If there are burns on the circuit board, see page 73

E23 **E23: Problems with the component (triac) controlling the drain pump** **E23**

Checks to perform:



E23




Fig. 4





Fig. 5



Fig. 6



If there are burns on the circuit board, see page 73

E24	E24: “Sensing” circuit of the component (triac) controlling the drain pump faulty	E24
------------	--	------------

Checks to perform:



Check that all the connectors are correctly inserted

Replace the circuit board and repeat the diagnostic cycle to check for any further alarms.



If there are burns on the circuit board, see page 73

E31	E31: The analogue pressure switch provides the main circuit board with a signal outside the limits	E31
------------	---	------------

Checks to perform:



check that all the connectors are correctly inserted

Measure that the circuit is closed between J10-1, J10-2, J10-3 and the connector of the analogue pressure switch (they are three independent wires) **-(see fig.7)-**.
 is the wiring between the main circuit board and the analogue pressure switch ok and is it connected correctly on both sides?

NO →

Reconnect and/or replace the wiring and repeat the diagnostic cycle to check for any further alarms.

↓
YES

Replace the analogue pressure switch and repeat the diagnostic cycle to check for any further alarms codes.
 Is the appliance displaying the same alarm code again?

↓
YES

Replace the main circuit board and repeat the diagnostic cycle to check for any further alarm codes.





Fig. 7






If there are burns on the circuit board, see page 73

E32	<p>E32: The analogue pressure switch causes an error during calibration</p> <p>(At the start of every cycle, the appliance drains to empty the tub and creates a level 0 to check the calibration of the analogue pressure switch)</p>	E32
------------	---	------------

Checks to perform:

! *Check that all the connectors are correctly inserted*



! *If there are burns on the circuit board, see page 73*

E35	E35: Water level too high	E35
	The main circuit board measures a water level, using the electronic pressure switch, of more than 300 mm for longer than 15 secs.	

Checks to perform:

Check that all the connectors are correctly inserted




Fig. 2





Fig. 8

If there are burns on the circuit board, see page 73

E38	E38: Internal pressure chamber is clogged	E38
	The analogue pressure switch is not able to measure any variation in the water level for at least 30 secs during drum rotation.	

Checks to perform:





Fig. 8







Fig. 2







E41	E41: Door open (device with 4 connections)	E41
	Maximum time exceeded (5 pulses per instant)	

Checks to perform:





E41 (device with 4 connections)







! If there are burns on the circuit board, see page 73

E42	E42: Problems opening door (device with 4 connections)	E42
	Maximum time exceeded (5 pulses per instant)	

Checks to perform:



E42 (device with 4 connections)



E43 **E43: Problems with the component (triac) controlling the door delay system (device with 4 connections)** **E43**

Checks to perform:

! Check that all the connectors are correctly inserted

To check the wiring, measure, with the door open, between the following wiring connectors **-(fig.4)-**:

- between J5-1 and J5-3, the circuit must NOT be open (measure the resistance value of the PTC).
- between J5-1 and J5-4, the circuit must NOT be open (measure the resistance value of the PTC).
- between wire J5-1 and J5-2, the circuit must be OPEN.

Is the system ok?

YES

Replace the circuit board and repeat the diagnostic cycle to check for any further alarms.

NO

Disconnect the door lock connectors and measure on the component:

- between connectors 3 and 4, the circuit must NOT be open (measure the resistance value of the PTC).
- between connectors 2 and 4, the circuit must NOT be open (measure the resistance value of the PTC).
- on the other hand, between connectors 4 and 5, the circuit must be OPEN (the numbers are printed on the component).

Is the door lock ok? **-(fig.9)-**

YES

Measure the continuity between connector J5 (main circuit board) and the door lock connector. Is the wiring ok?

YES



Replace the circuit board and repeat the diagnostic cycle to check for any further alarms.

NO

Replace the door lock and repeat the diagnostic cycle to check for any further alarms.

NO

Replace the wiring and repeat the diagnostic cycle to check for any further alarms.



! If there are burns on the circuit board, see page 73

E44	E44: Door closed “sensing” circuit faulty	E44
------------	--	------------

Checks to perform:



Check that all the connectors are correctly inserted

Replace the circuit board and repeat the diagnostic cycle to check for any further alarms.

E45	E45: Problems with the “sensing” circuit of the component (triac) controlling the door delay system	E45
------------	--	------------

Checks to perform:



Check that all the connectors are correctly inserted



Replace the circuit board and repeat the diagnostic cycle to check for any further alarms.



If there are burns on the circuit board, see page 73

E52	E52: No signal from motor tachometric generator (first part)	E52
	Cycle interrupted after 5 attempts during the cycle, immediately if recognised at the start of the cycle or during diagnostics.	

Checks to perform:



E52



Fig. 12




Fig. 13




Fig. 11





Fig. 14



Fig. 10



! If there are burns on the circuit board, see page 73

E52	E52: No signal from motor tachometric generator (second part)	E52
	Cycle interrupted after 5 attempts during the cycle, immediately if recognised at the start of the cycle or during diagnostics.	

Checks to perform:

! Check that all the connectors are correctly inserted

The motor never runs

To check the wiring, measure (Ω) between the following wiring connectors of the motor control board **-(fig.14)-** and compare the values with **(see page 41: point 4 - motor parameters)**

- between J2-6 and J2-7, a value as in point 4 - **B** (Stator) must be found
- between J2-5 and J2-6, a value as in point 4 - **C** (Stator) must be found
- between J2-5 and J2-7, a value as in point 4 - **D** (Stator) must be found

Are the values correct?

NO →

Check the motor as on **page 41**.
Is the motor ok?

NO →




Replace the motor and repeat the diagnostic cycle to check for any further alarms.

YES ↓

Check/replace the wiring and repeat the diagnostic cycle to check for any further alarms.

YES ↓


Replace the motor control board and repeat the diagnostic cycle to check for any further alarms.



! If there are burns on the circuit board, see page 73

How to check three-phase motors

- 1) Check the connection blocks (wiring) and for the presence of any protruding/kinked terminals.
- 2) Check for the presence of any marks/residue/water or detergent deposits on the motor and where these come from.
- 3) Proceed by checking for any windings/earthed parts or parts with poor earthing insulation. Use a tester with a minimum capacity of 40 MΩ: between each individual terminal and the motor casing, read ∞ (fig.10).
- 4) Proceed by checking each individual winding according to the following table (fig.11).



	TERMINALS ON MOTOR TERMINAL BLOCK	CONTROLS	MOTORS		
			C.E.SET.	ACC (SOLE) NIDEC	ECM
A	4-5	Winding of tachometric generator	108÷133	169÷207	85÷98
B	1-2	Stator winding	5.0÷5.8	5.0÷5.8	5.0÷5.8
C	2-3	Stator winding	5.0÷5.8	5.0÷5.8	5.0÷5.8
D	3-1	Stator winding	5.0÷5.8	5.0÷5.8	5.0÷5.8



Fig. 10






Fig. 11




If there are burns on the circuit board, see page 73

E57	E57: Inverter is drawing more than 16A current	E57
	Abnormal current absorption by Motor	

Checks to perform:



E57



! If there are burns on the circuit board, see page 73

E58	E58: Inverter is drawing more than 4A current	E58
	Abnormal current absorption by Motor	

Checks to perform:

! Check that all the connectors are correctly inserted





Fig. 14

! If there are burns on the circuit board, see page 73

E58



Fig. 15




Fig. 16



Fig. 17




Fig. 13





Fig. 10

! If there are burns on the circuit board, see page 73



E59	E59: No signal from the tachometric generator	E59
	The lack of signal should last at least 3 seconds	

Checks to perform:



E59




Fig. 12




Fig. 11




Fig. 13





Fig. 14



Fig. 10



! If there are burns on the circuit board, see page 73

E5A	E5A: Overheating on Inverter board heat dissipator	E5A
	The dissipator exceeds a temperature of 88 °C	

Checks to perform:

! *Check that all the connectors are correctly inserted*

Have continuous wash cycles been performed, or has the wash cycle been performed with too heavy a laundry load?

YES →

Leave pauses between one cycle and the next or reduce the laundry load inside the drum.

NO ↓

Check whether the drum turns freely without posing any resistance **-(see fig.15)-**.
Is the drum having difficulty rotating?

YES →

Check whether the friction is caused by the motor **-(fig.17)-** or by the tub bearings **-(fig.16)-**. Replace the defective component. Repeat the diagnostic cycle to check for any further alarms.

NO ↓

Replace the motor control board and repeat the diagnostic cycle to check for any further alarms.



Fig. 15




Fig. 14




Fig. 16





Fig. 17

! *If there are burns on the circuit board, see page 73*

E5C	E5C: The Inverter board input voltage is too high (beyond 430V)	E5C
	The voltage should stay above 430V for at least 5 seconds	



Checks to perform:



E5d	E5d: Data transfer error between Inverter board and main circuit board	E5d
The lack of communication must last at least 2 sec.		

Checks to perform:

check that all the connectors are correctly inserted



If there are burns on the circuit board, see page 73

E5E	E5E: Communication error between Inverter board and main circuit board	E5E
	Communication protocol between the two boards not aligned	

Checks to perform:




Replace the motor control board and repeat the diagnostic cycle to check for any further alarms.

E5F	E5F: Inverter board fails to start the motor	E5F
------------	---	------------

Checks to perform:






Replace the motor control board and repeat the diagnostic cycle to check for any further alarms.






E5H	E5H: The Inverter board input voltage is too low (less than 175V)	E5H
	The voltage should stay below 175V for at least 5 seconds	

Checks to perform:



E62	E62: Overheating during washing	E62
The temperature of the NTC probe exceeds 88 °C for more than 5 mins.		

Checks to perform:



E66 **E66: Heating element power supply relay faulty** **E66**

Checks to perform:

! Check that all the connectors are correctly inserted

Measure between the connector J3-1/J3-2 of the main circuit board and the appliance body.
-(fig.6)- Is there any dispersion?

NO

Replace the circuit board and repeat the diagnostic cycle to check for any further alarms.

YES




Detach the connectors and measure between the heating element and the earth contact.
-(fig.19)- Is the circuit open?

NO

Replace the heating element and repeat the diagnostic cycle to check for any further alarms.

YES

Check/replace the wiring and repeat the diagnostic cycle to check for any further alarms.



! If there are burns on the circuit board, see page 73

E68 **E68: Washing heating element leakage** **E68**

Checks to perform:

! Check that all the connectors are correctly inserted

Run the diagnostic cycle and fill with water up to the door level to make sure the heating element is completely submerged. Measure between the wiring connector J3-1/J3-2 and the appliance body. **-(see fig.6)-** Is the circuit open?

NO

Detach the connectors and measure between the heating element and the earth contact. **-(see fig.19)-** Is the circuit open?

NO



Run phase 9 of the diagnostic cycle, drain water from the tub. Replace the heating element and repeat the diagnostic cycle to check for any further alarms.

YES

Check/replace the wiring and repeat the diagnostic cycle to check for any further alarms.

YES

Replace the main circuit board and repeat the diagnostic cycle to check for any further alarms.






! If there are burns on the circuit board, see page 73

E69 **E69: Washing heating element damaged** **E69**

Checks to perform:

! Check that all the connectors are correctly inserted




! If there are burns on the circuit board, see page 73

E6A **E6A: Heating relay “sensing” faulty** **E6A**

Checks to perform:

 Check that all the connectors are correctly inserted



Replace the circuit board and repeat the diagnostic cycle to check for any further alarms.


 If there are burns on the circuit board, see page 49

E6H **E6H: Heating element power relay faulty (incongruence between “sensing” and relay status)** **E6H**

Checks to perform:

 Check that all the connectors are correctly inserted



 If there are burns on the circuit board, see page 73

E71	E71: Washing NTC probe faulty	E71
	Voltage value out of range (short-circuit or open circuit)	

Checks to perform:

Check that all the connectors are correctly inserted

Run **phase 7** of the diagnostic cycle and wait for the water to fill. Switch the appliance off and measure the value of the NTC probe between contacts J10-4 and J10-5 of the wiring connector **-(see fig.4)-**.
Is the value correct?
(between 5.7÷6.3 kΩ at 20 °C)

NO →

Detach the connector and measure directly on the NTC probe. **-(see fig.18)-**
Is the value correct?
(5.7÷6.3 kΩ at 20 °C)

NO →

Run **phase 9** of the diagnostic cycle, drain water from the tub. Replace the washing heating element and repeat the diagnostic cycle to check for any further alarms.

YES ↓

Measure between terminals J10-4, J10-5 of the NTC connector and the appliance body **-(see fig.6)-**.
Is there any dispersion?

NO →

Check/replace the wiring and repeat the diagnostic cycle to check for any further alarms.

YES ↓

Detach the connector and measure directly between the terminals of the NTC probe and the appliance body. **There must be water in the tub.**
Has the dispersion been measured?

NO →

Replace the circuit board and repeat the diagnostic cycle to check for any further alarms.

YES ↓

Run **phase 9** of the diagnostic cycle, drain water from the tub. Replace the washing heating element and repeat the diagnostic cycle to check for any further alarms.



Fig. 6




Fig. 18

If there are burns on the circuit board, see page 73

E74 **E74: NTC probe improperly positioned** **E74**

Checks to perform:

! Check that all the connectors are correctly inserted

Is the probe visibly positioned correctly in its seat? **-(see fig.21)-**

NO

Reposition the probe in its seat and repeat the diagnostic cycle to check for any further alarms.

YES

Measure the value of the NTC probe ($5.7 \div 6.3 \text{ k}\Omega$ at 20°C) between contacts J10-4 and J10-5 of the wiring connector **-(fig.4)-**. Is the value correct? (between 5.7 and $6.3 \text{ k}\Omega$ at 20°C)

NO

Replace the washing heating element and repeat the diagnostic cycle to check for any further alarms.

YES

Run **phase 7** of the diagnostic cycle and wait for the water to fill. Wait in this phase for five minutes. Switch the appliance off and measure the value of the NTC probe between contacts J10-4 and J10-5 of the wiring connector **-(fig.4)-**. Is the value below $5 \text{ k}\Omega$?

NO

Run **phase 9** of the diagnostic cycle, drain water from the tub.

!!CAUTION: THE WATER COULD BE SCALDING HOT!!

Replace the washing heating element and repeat the diagnostic cycle to check for any further alarms.

YES

Replace the circuit board and repeat the diagnostic cycle to check for any further alarms.




Fig. 4




Fig. 21

! If there are burns on the circuit board, see page 73

E83	E83: Error reading the programme selector code	E83
Selector position code not envisaged by the configuration data or configuration error		

Checks to perform:

 **Check that all the connectors are correctly inserted**

Turn the appliance on, turn the programme selector to every setting: wait at least 10 seconds on each of the settings before moving on to the next one. Is alarm E83 shown again?

NO →

Repeat the diagnostic cycle to check for any further alarms.

YES ↓


Check for any friction between the control panel and the knob. Is it difficult to turn the knob?

NO →

Replace the display board and repeat the diagnostic cycle to check for any further alarms.

YES ↓

Repair the coupling between the control panel/ selector knob. Repeat the diagnostic cycle to check for any further alarms.


 **If there are burns on the circuit board, see page 73**

E86	E86: Programme selector configuration error	E86
------------	--	------------

Checks to perform:

 **Check that all the connectors are correctly inserted**

Replace the display board and run the diagnostic cycle to check for any further alarms.


 **If there are burns on the circuit board, see page 73**

E87	E87: User Interface microcontroller defective	E87
------------	--	------------

Checks to perform:

 **Check that all the connectors are correctly inserted**

Replace the display board and run the diagnostic cycle to check for any further alarms.

 **If there are burns on the circuit board, see page 73**


E91	E91: Communication error between the display board and the main circuit board	E91
	Inconsistency between configuration values on starting the appliance	

Checks to perform:



Check the wiring between the main circuit board and the display board:

- ▶ Detach and reconnect the connectors on both boards several times.
- ▶ Measure the continuity between connector J4 (main circuit board) and J3 (display board).
Is the wiring ok?



Replace / repair the wiring and repeat the diagnostic cycle to check for any further alarms.





Replace the main circuit board and repeat the diagnostic cycle to check for any further alarms.
Is the appliance still displaying E91?



Appliance ok.



Replace the display board and repeat the diagnostic cycle to check for any further alarms.



E92	E92: protocol incongruence	E92
	Inconsistency between configuration values on starting the appliance	

Checks to perform:



Check that all the connectors are correctly inserted

Incorrect configuration possible.
Replace the circuit board and repeat the diagnostic cycle to check for any further alarms.

E93	E93: Appliance configuration error	E93
	Inconsistency between configuration values on starting the appliance	

Checks to perform:



Check that all the connectors are correctly inserted

Incorrect configuration possible.
Replace the circuit board and repeat the diagnostic cycle to check for any further alarms.

E94	E94: Incorrect configuration of washing cycle	E94
	Inconsistency between configuration values on starting the appliance	

Checks to perform:



Check that all the connectors are correctly inserted

Incorrect configuration possible.
Replace the circuit board and repeat the diagnostic cycle to check for any further alarms.

E97	E97: Inconsistency between control selector version and configuration data	E97
	Discrepancy between programme configuration data and selector recognition data	

Checks to perform:



Check that all the connectors are correctly inserted

Incorrect configuration possible.
Replace the circuit board and repeat the diagnostic cycle to check for any further alarms.

E98	E98: Communication error between main PCB and Inverter board	E98
	Incompatibility between the main circuit board and the Inverter board	

Checks to perform:



Check that all the connectors are correctly inserted

Incorrect configuration possible.
Replace the main circuit board/Inverter board and repeat the diagnostic cycle to check for any further alarms.



If there are burns on the circuit board, see page 73

E9C	E9C: Display board configuration error	E9C
------------	---	------------

Checks to perform:



Check that all the connectors are correctly inserted

Incorrect configuration possible.
Replace the circuit board and repeat the diagnostic cycle to check for any further alarms.

E9E	E9E: Display board sensor/touch key faulty	E9E
------------	---	------------

Checks to perform:



Check that all the connectors are correctly inserted

Display board faulty.
Replace the display board and repeat the diagnostic cycle to check for any further alarms.




If there are burns on the circuit board, see page 73

EC1	EC1: Water fill solenoid valves blocked	EC1
	The flowmeter has to fill water even with the solenoid valve not piloted	


Checks to perform:

! Check that all the connectors are correctly inserted



Tab. 1

Between J7-1 and J7-3	wash solenoid valve
Between J7-4 and J7-6	pre-wash solenoid valve
Between J8-1 and J8-3	third solenoid valve
Between J8-4 and J8-6	hot water solenoid valve



! If there are burns on the circuit board, see page 73

EC2	EC2: Problem with weight sensor	EC2
------------	--	------------

Checks to perform:



Turn the appliance off and back on again, enter the diagnostic cycle. Does the EC2 alarm appear again?

NO →

Appliance ok.

YES ↓

Measure the continuity between connector J15 (main circuit board **fig.4**) and the weight sensor connector. Is the wiring ok?

NO →

Replace the wiring and repeat the diagnostic cycle to check for any further alarms.

YES ↓

Replace the shock absorber and repeat the diagnostic cycle to check for any further alarms.






Fig. 4



EC3	EC3: Problem with weight sensor	EC3
	No signal or outside the limits	

Checks to perform:

! Check that all the connectors are correctly inserted

Turn the appliance off and back on again, enter the diagnostic cycle. Does the EC3 alarm appear again?

NO →

Appliance ok.

YES ↓

Measure the continuity between connector J15 (main circuit board **fig.4**) and the weight sensor connector. Is the wiring ok?

NO →

Replace the wiring and repeat the diagnostic cycle to check for any further alarms.

YES ↓

Replace the shock absorber and repeat the diagnostic cycle to check for any further alarms.





Fig. 4



! If there are burns on the circuit board, see page 73

EF1	EF1: Drain hose blocked/kinked/too high; drain filter clogged/dirty	EF1
------------	--	------------

Checks to perform:



Check that all the connectors are correctly inserted

This warning only appears at the end of the cycle. The appliance detected long drainage phases during the cycle. (E.g.: More than 20 seconds when draining after rinses). Check/clean the drain filter.

EF2	EF2: Excessive detergent dosing; drain hose kinked/blocked; drain filter dirty/clogged	EF2
------------	---	------------

Checks to perform:



Check that all the connectors are correctly inserted

This is an excessive detergent dosing warning. The system detected too much foam was forming during the drain phases. Advise the Customer to use the correct quantity of detergent and to make sure the filter and drain circuit are clean.

EF3	EF3: Aqua Control device triggered	EF3
------------	---	------------

Checks to perform:



Check that all the connectors are correctly inserted

This warns about the presence of water at the bottom of the appliance. Check for any water leaks and that the Aqua Control device float is positioned correctly.
Or caused by excessive overheating of the drain pump. Check for any items which may obstruct the normal operation of the rotor.

EF4	EF4: Water fill pressure too low and solenoid valve open	EF4
------------	---	------------

Checks to perform:



Check that all the connectors are correctly inserted

It is a warning that the water pressure is too low. If the water pressure is correct, check: the wiring of the flowmeter and the Flowmeter.

EF5	EF5: Unbalanced load, spin phases skipped.	EF5
------------	---	------------

Checks to perform:



Check that all the connectors are correctly inserted

This is an unbalanced load warning. The appliance detected an extremely unbalanced load during the spin phases. Advise the customer to load more washing into the drum and not just individual garments.



If there are burns on the circuit board, see page 73

EF6	EF6: Reset appliance.	EF6
------------	------------------------------	------------

Checks to perform:

Check that all the connectors are correctly inserted

No action to be performed, if continues, replace the main circuit board.


EH1	EH1: Mains frequency incorrect	EH1
Power supply frequency out of configured range		

Checks to perform:

Check that all the connectors are correctly inserted

Important

The appliance remains in alarm status until the mains frequency returns to the correct values or the appliance is switched off (programme selector set to "0"). Only the family of the alarm is displayed and the diagnostics mode cannot be accessed. The complete alarm can only be read when the situation has normalised.




EH2	EH2: Supply voltage too high	EH2
Supply voltage value higher than the one configured (for more than 10 seconds)		

Checks to perform:

Check that all the connectors are correctly inserted

Important

The appliance remains in alarm status until the mains frequency returns to the correct values or the appliance is switched off (programme selector set to "0"). Only the family of the alarm is displayed and the diagnostics mode cannot be accessed. The complete alarm can only be read when the situation has normalised.





EH3	EH3: Supply voltage too low	EH3
Supply voltage value higher than the one configured		

Checks to perform:

 **Check that all the connectors are correctly inserted**

Important


 The appliance remains in alarm status until the mains frequency returns to the correct values or the appliance is switched off (programme selector set to "0"). Only the family of the alarm is displayed and the diagnostics mode cannot be accessed. The complete alarm can only be read when the situation has normalised. 

Is the supply line disturbed or the mains voltage out of range?

NO → Replace the main circuit board and repeat the diagnostic cycle to check for any further alarms.

YES ↓

Have the electrical system of the home checked / repaired by the proper Body.


 **If there are burns on the circuit board, see page 73**

EH4	EH4: "zero watt" relay not functioning	EH4
------------	---	------------

Checks to perform:

 **Check that all the connectors are correctly inserted**

Replace the main circuit board and repeat the diagnostic cycle to check for any further alarms.


 **If there are burns on the circuit board, see page 73**

EHE	EHE: Inconsistency between safety relay (main circuit board) and safety "sensing" circuit	EHE
------------	--	------------

Checks to perform:

 **Check that all the connectors are correctly inserted**

Replace the main circuit board and repeat the diagnostic cycle to check for any further alarms.


 **If there are burns on the circuit board, see page 73**

EHF	EHF: Safety "sensing" circuit faulty	EHF
Input voltage microprocessor wrong		


Checks to perform:

 **Check that all the connectors are correctly inserted**

Replace the main circuit board and repeat the diagnostic cycle to check for any further alarms.

 **If there are burns on the circuit board, see page 73**


8 WM OPERATING CIRCUIT DIAGRAM



8.1 Key to circuit diagram WM

Appliance electrical components	PCB components	
<ol style="list-style-type: none"> 1. Main circuit board 2. Door safety interlock (with light micro-switch) 2a Door safety interlock (without light micro-switch) 3. Electronic pressure switch 4. NTC (washing) 5. Flow sensor 6. Weight sensor 7. Pre-wash solenoid 8. Wash solenoid 9. Bleach solenoid valve 10. Hot water solenoid 11. Heating element 12. Display board 13. Motor control board (Inverter) 14. Triple-phase motor 15. Tachometric generator (motor) 16. Circulation pump 17. Aqua control sensor 18. Drain pump 19. Drum light 	<p>DRAIN_TY DOOR_TY DOOR_CLOSE_TY REC PUMP_TY PWELT_TY WELV_TY BELT_TY HELT_TY K1 K2</p>	<p>Drain pump Triac Door interlock Triac Door interlock Triac Circulation pump TRIAC switch Pre-wash solenoid Triac Wash solenoid Triac Electronically controlled TRIAC bleach valve Hot water solenoid triac Heating element relay Heating element relay</p>

8.2 Main circuit board connectors




J15	J10
MACS communication J15-1 Vee 12V J15-2 5V J15-3 Rx/Tx J15-4 GND	J10-1 Analogue pressure switch (+5V) J10-2 Analogic pressure switch (GND) J10-3 Analogic pressure switch (signal) J10-4 NTC temperature probe (signal) J10-5 NTC temperature probe (+5V)
J16	J10-6 Flowmeter (signal) J10-7 Flowmeter (GND) J10-8 Flowmeter (+5V)
MACS communication J15-1 Vee 12V J15-2 5V J15-3 Rx/Tx J15-4 GND	J7
J4	J7-1 Wash solenoid valve (Triac) J7-3 Wash solenoid valve (Line) J7-4 Pre-wash solenoid valve (Line) J7-6 Pre-wash solenoid valve (Triac)
J4-1 Vee 12V0 J4-2 5V J4-3 Rx/Tx J4-4 GND J4-5 ON/OFF 2 J4-6 ON/OFF 1	J1
J8	J1-1 line (neutral) J1-2 line
J8-1 Bleach solenoid valve (Triac) J8-3 Bleach solenoid valve (Line) J8-4 Hot water solenoid valve (Line) J8-6 Hot water solenoid valve (Triac)	J5
J2	J5-1 Door lock (Line) J5-2 Door lock (Door line) J5-3 Door lock (Triac PTC) J5-4 Door lock (Triac)
J2 Earthing	J14
J6	J14 Serial interface: J9-1 ASY_IN J9-2 ASY_OUT J9-3 +5V J9-4 GND
J6-1 Aqua control device (Neutral) J6-2 Aqua control device (Line) J6-3 Drain pump (Triac) J6-4 Drain pump (Line) J6-5 Circulation pump (Line) J6-6 Circulation pump (Triac)	J3
J3	J3-1 heating element (Neutral Relay) J3-2 heating element (Line Relay)
J9	J12
J9-1 FCV power supply (Neutral) J9-1 FCV power supply (Relay)	J11-1 DSP drum position (+5V) J11-2 DSP drum position (GND) J11-1 DSP drum position (signal)

8.3 Burns on the main circuit board EWM10931

In the event of burns on the main circuit board, check whether the problem was caused by another electrical component (short-circuits, poor insulation, water leaks). Use the figures that follow to pinpoint the component which may have caused the problem, depending on the area of the burns.

The type of board illustrated is the one with the largest number of components; other boards do not feature some of these components.



1. Anti-disturbance filter area
2. Power supply area
3. Satellite board communication area
4. Drum light circuit area
5. Analogue level sensor, wash NTC temperature probe, flowmeter and weight sensor area
6. Drum positioning sensor area (top loading)

7. Zero watt circuit area
8. Water fill solenoid valves area (bleach and 3rd)
9. Water fill solenoid valves area (wash and pre-wash)
10. Drain pump and circulation pump area
11. Door lock area
12. Heating element area
13. Relay FCV area (motor)

