Programme Table

Programmes		Prewash			Wash				1st cold rinse			2nd cold rinse			Additional rinse		Warm rinse			Dry		
Туре	Programmes	Heating (Temperature °C)	Washing time after heating (min.)	Wash type	1st Heating (Temperature °C)	Washing time after heating (min.)	2nd Heating (Temperature °C)	Washing time after heating (min.)	Wash type	Washing time (minutes)	Washing time (minutes)	Wash type	Washing time (minutes)	Washing time (minutes)	Wash type	Washing time (minutes)	Wash type	Heating (Temperature °C)	Washing time after heating (min.)	Wash type	Drying (min.)	Cycle time (minutes)
IC	Intensive (care)	55°C	10'	ctrl	55°C	5'	68°C	14'	ctrl	3' (<65°C)	3'	ctrl	3'	3'	ctrl	5'	PW1	69°C	27'	ctrl	24'	127'
N2	Regular (full speed)		6'	ctrl	50°C	4'	68°C	8'	ctrl		4'	ctrl				5'	PW1	69°C		ctrl	24'	100'
N3	Gentle		6'	PW1	50°C	2'	55°C	12'	PW1		4'	PW1				5'	PW1	69°C	1'	PW1	24'	98'
E 1	Energy label Axx		10'	PW1	15,5' <62°C	42'			PW1	5' (<60°C)		PW1				4'	PW1	16' <68°C	2'	PW1	54'	162'
Auto 2	Auto 50-65°C		8'	ctrl	50°C	4'	68°C	8'	ctrl		4'	PW1				5'	PW1	69°C	1'	PW1	24'	92-115'
Q4	Rinse & Hold		8'	PW1																		12'
Q5	Quick 30 min.				14,5' <65°C				ctrl							5'	PW1	9' <68°C		ctrl		31'
Q7	Glass care				45°C	9'			PW1	5' (<60°C)		PW1				3'	PW1	61°C		PW1	24'	73'

Note: The total duration of the programmes is approximate and does not include the additional rinse, which is optional. The regeneration times in the different phases are not reported, as they are "Una Tantum" and can be performed in any cycle.

ctrl ⇒ Wash at constant speed of 2800 rpm. **PW** ⇒ Pulse washing 1600 > 2800 rpm.