

## Service Information

### Thermo mastic

Since we made technical modifications in the construction and production. Thermo mastic is **no longer used and no longer desired** on the miniBars / miniCools for following models:

1. **Starting with serial number 923XXXXX**  
RH 136, RH 137, RH 330, RH 340, RH 341, RH 355, RH 360, RH 361  
EA 330, EA 355
2. **Facelift models, RH 430, RH 436, RH 440, RH 441, RH 447, RH 455, RH 460, RH 461**  
are generally produced without thermo mastic.

#### Negative effects thermo mastic:

- because of a new ecologically mixture
- dropp off, blockage of the drip-channel
- optical bad impression

Please note in Servicefall (e.g. changing cooling unit) !



**For models RH 356 and RH 456 we could not realize the modifications.  
Please use thermo mastic furthermore!**