

## **SERVICE BULLETIN**

Dometic GmbH, In der Steinwiese 16, D-57074 Siegen

---

RM 7211/71/75/91/95, RM 7361/65/71/91/95, RM 7401/05, RM 7501/41/45/51/55, RM 7601/05/51/55, RM 7801/05/51/55

### **How to handle with broken axes on the MES or AES electronics**

It might happen that the axes of operating knobs on the electronics could break.  
A broken axis should be replaced by a new axis.  
Exchanging the electronic board is not necessary.  
The following pictures show how to remove remaining pieces in the potentiometer.

