

SET TEMPERATURE DISPLAYED INSTEAD OF THE ACTUAL ONE

DESCRIPTION:

On the appliances listed in Table A, the following complain can be raised by the Customer:

- a fluctuation of the actual refrigerator temperature on the display is visible, for example when opening the refrigerator door for a short period

This fluctuation, affected also by high room temperature, must be considered normal and is not linked to any product malfunctioning.

Nevertheless, in order to avoid this kind of customer claim, a service solution have been developed

SOLUTION:

A pcb board (part number 242504392/0) is available for service; this pcb is equipped with customized software that shows on display the set temperature instead of the actual temperature.

Replace the current power board on the appliance with electronic board code 242504392/0.

Solution is applicable for all brands.

Table A

PNC
925 034 xxx