


## DOOR LATCH BROKEN

### DESCRIPTION:

Consumer reports that the door latch is broken. Problem can occur due to mechanical stresses in the material.




### SOLUTION:

Replace the broken door latch with a new spare part:

| Spare part number | Description                         |
|-------------------|-------------------------------------|
| 8086811083        | catch, porthole, glass door, Pilot2 |

New door latch is more robust and resistant for mechanical stress.



### QES CODE:

During the intervention please use work codes:

|           |                                       |
|-----------|---------------------------------------|
| Component | G45 203 Locking device                |
| Defect    | G45 08 Cracked/Split/Broken/Fractured |

**MODELS INVOLVED:**

All condense dryers and heat pump dryers with plastic door latch

**REVISION:**

| <b>Revision</b> | <b>Date</b> | <b>Description</b>       | <b>Author</b> | <b>Approved by - on</b>   |
|-----------------|-------------|--------------------------|---------------|---------------------------|
| 00              | 05/2018     | Document Creation        | Marcin Pluta  | Marek Kapustka 24.05.2018 |
| 01              | 07/2018     | Door latch gray - update | Marcin Pluta  | Marek Kapustka 10.07.2018 |