

COMPRESSOR RUNNING CONTINUOUSLY - APPLIANCE TOO WARM**DESCRIPTION:**

The appliance is too warm and the compressor is running continuously.

SOLUTION:

Check for leaks:

1. Start the compressor.
2. Check for leaks using foam on the pressure side.
3. Leaks on the suction side can be checked when the compressor is off and the pressure has equalized.

Solution:

1. Open and clean the system
2. Exchange the dryer/filter
3. Refill and close the system.

Use the following QES Codes when reporting the Service Order:

Component	335, 337, 341, 342
Defect	08,11,12,29

MODELS INVOLVED:

PNC 9250** ***

REVISION:

Revision	Date	Description	Author	Approved by - on
00	10/2019	Document Creation	Anna Grimlund	Attila Héri/ Judit Hudákné Szabó