



Handles rub against each other in side-by-side installations

DESCRIPTION:

The handles rub against each other when opening/closing the appliance.

SOLUTION:

Add two strips of adhesive sponge tape on the side of one of the appliances, one at the top and one at the bottom. This will create a slight distance between the appliances.



1. Prepare the adhesive sponge tape



2. Pull out one appliance at least 5 cm from the niche.



3. Stick the adhesive sponge tape to the side of the applicane at the top.
Recommended position:
 - **30 cm** from the top.
 - **3 cm** from the edge.



4. Stick the adhesive sponge tape to the side of the applicane at the bottom.
Recommended position:
 - **30 cm from the bottom.**
 - **3 cm from the edge.**



5. Ensure that both strips of adhesive sponge tape are fixed to the appliance.

6. Move back the appliance and check the handles.

SPARE PART NUMBER:

| New spare part code | Description |
|---------------------|-----------------------|
| 2109020046 | Adhesive tape, sponge |

OES CODE

| | |
|-----------|----------|
| Component | 207, 227 |
| Defect | 08 |

MODELS INVOLVED:

| | | | | | |
|-------------|-------------|-------------|-------------|-------------|-------------|
| 92505200200 | 92505210205 | 92505225102 | 92505257501 | 92505275601 | 92505284203 |
| 92505200201 | 92505210206 | 92505226900 | 92505257502 | 92505275602 | 92505284300 |
| 92505200400 | 92505210400 | 92505226901 | 92505258300 | 92505275603 | 92505284301 |
| 92505200401 | 92505210401 | 92505227400 | 92505258301 | 92505275604 | 92505284302 |
| 92505200500 | 92505213400 | 92505227401 | 92505258302 | 92505275605 | 92505284303 |
| 92505200501 | 92505213401 | 92505227402 | 92505260400 | 92505275700 | 92505284304 |
| 92505200502 | 92505213402 | 92505227403 | 92505260401 | 92505275701 | 92505287900 |
| 92505202900 | 92505213403 | 92505227404 | 92505260700 | 92505275702 | 92505287901 |
| 92505202901 | 92505213404 | 92505227405 | 92505260701 | 92505275703 | 92505287902 |
| 92505203000 | 92505213405 | 92505227406 | 92505260702 | 92505275704 | 92505287903 |
| 92505203001 | 92505213406 | 92505227500 | 92505260900 | 92505275705 | 92505287904 |
| 92505203100 | 92505215000 | 92505227501 | 92505260901 | 92505275706 | 92505287905 |
| 92505203101 | 92505215001 | 92505227502 | 92505261500 | 92505277600 | 92505288800 |
| 92505203102 | 92505215200 | 92505227503 | 92505261501 | 92505277601 | 92505289000 |
| 92505203700 | 92505215700 | 92505227504 | 92505261600 | 92505277602 | 92505289100 |
| 92505203701 | 92505217800 | 92505227505 | 92505261601 | 92505277700 | 92505289200 |
| 92505204400 | 92505217801 | 92505227506 | 92505261602 | 92505277701 | 92505289201 |
| 92505204401 | 92505217802 | 92505229400 | 92505261700 | 92505277702 | 92505289800 |
| 92505204402 | 92505217900 | 92505229401 | 92505261701 | 92505280000 | 92505289900 |
| 92505205200 | 92505217901 | 92505229402 | 92505262000 | 92505280001 | |
| 92505205201 | 92505217902 | 92505229403 | 92505262001 | 92505280002 | |
| 92505205202 | 92505218000 | 92505229500 | 92505262100 | 92505282000 | |
| 92505205300 | 92505218001 | 92505229501 | 92505262101 | 92505282001 | |
| 92505205301 | 92505218002 | 92505229502 | 92505262600 | 92505282002 | |
| 92505205302 | 92505218300 | 92505229503 | 92505262800 | 92505282100 | |
| 92505206700 | 92505218302 | 92505229600 | 92505262801 | 92505282101 | |
| 92505206701 | 92505218303 | 92505229700 | 92505263100 | 92505282102 | |
| 92505207500 | 92505218400 | 92505230400 | 92505263101 | 92505282400 | |
| 92505209200 | 92505218401 | 92505230401 | 92505263102 | 92505282401 | |
| 92505209700 | 92505218402 | 92505230500 | 92505263200 | 92505283200 | |
| 92505209701 | 92505218500 | 92505230501 | 92505263201 | 92505283201 | |
| 92505209702 | 92505218501 | 92505230600 | 92505263202 | 92505283202 | |
| 92505209703 | 92505218502 | 92505230601 | 92505263300 | 92505283203 | |

| | | | | | |
|-------------|-------------|-------------|-------------|-------------|--|
| 92505209704 | 92505219600 | 92505230700 | 92505263301 | 92505283300 | |
| 92505209800 | 92505219700 | 92505230701 | 92505263302 | 92505283301 | |
| 92505209801 | 92505219800 | 92505231200 | 92505263600 | 92505283302 | |
| 92505209802 | 92505220400 | 92505231300 | 92505263601 | 92505283303 | |
| 92505209803 | 92505220401 | 92505252400 | 92505264000 | 92505283400 | |
| 92505209804 | 92505220402 | 92505252401 | 92505264001 | 92505283401 | |
| 92505209805 | 92505220500 | 92505252402 | 92505264100 | 92505283402 | |
| 92505210000 | 92505220501 | 92505255200 | 92505264101 | 92505283403 | |
| 92505210001 | 92505220502 | 92505255201 | 92505264600 | 92505283500 | |
| 92505210002 | 92505220600 | 92505255202 | 92505265000 | 92505283501 | |
| 92505210003 | 92505220601 | 92505255600 | 92505265400 | 92505283502 | |
| 92505210200 | 92505220602 | 92505255601 | 92505265500 | 92505283503 | |
| 92505210201 | 92505222100 | 92505255602 | 92505265800 | 92505283504 | |
| 92505210202 | 92505225000 | 92505255603 | 92505265900 | 92505284200 | |
| 92505210203 | 92505225100 | 92505257100 | 92505266300 | 92505284201 | |
| 92505210204 | 92505225101 | 92505257500 | 92505275600 | 92505284202 | |

REVISION:

| Revision | Date | Description | Author | Approved by - on |
|----------|---------|-------------------|---------------|---|
| 00 | 09/2021 | Document Creation | Anna Grimlund | Szabina Czuczorné Seres László Kabai |