



- |                                  |  |
|----------------------------------|--|
| A.i.f = Anti-interference filter | Ta = Tachometer, inside motor          |
| b0 = Line switch                 | Te = Termistor NTC                     |
| b2 = Door switch                 | Pl = Pilot lamp                        |
| b7 = Floater switch              | S1 = Inlet valve                       |
| b9 = Salt switch                 | S2/4 = Detergent/Rinse aid coil        |
| b10 = Rinse aid switch           | S3 = Regeneration valve                |
| f3.2 = Overheating thermostat    | ● = 2.8mm connection on component      |
| f3.3 = Overheating protector     | ● = 6.3mm -- -- component              |
| f5.1 = Level pressostat          | ● = PCB -- -- component                |
| H1 = Heater                      | ○ = 6.3mm -- -- electronic             |
| K1 = Start capacitor             | ○ = PCB -- -- electronic               |
| m2 = Main pump                   | — = Internal connection on electronic- |
| m3 = Drain pump                  | --- = or component                     |
| Nt = Net terminal                | ---                                    |

B Boiling protector removed		ALJ	TN040125	04.03.26
POS	MODIFICATIONS	SIGNATURE	REQUEST	DATE
MATERIAL		MODEL <b>MD 20</b>		SCALE
TREATMENT		DESIGN USERS		REPLACES No <b>Rev A</b>
DESIGN OWNER	DRN	CHD	DATE <b>04.02.04</b>	DERIVED FROM No
TN	ALJ	APPR	<b>TN040044</b>	SUPPLY SPECIFICATIONS No
TITLE El. circuit diagram. With softener				
NUMBER <b>155 11 82-00</b>				REV <b>B</b>



VARIANT NUMBER	MODEL	CHANGRS FROM THE BASIC NUMBER
----------------	-------	-------------------------------