








- A.i.f = Anti-interference filter
- b0 = Line switch
- b2 = Door switch
- b7 = Floater switch
- b10 = Rinse aid switch
- f3.2 = Overheating thermostat
- f3.3 = Overheating protector
- f5.1 = Level pressostat
- H1 = Heater

- K1 = Start capacitor
- m2 = Main pump
- m3 = Drain pump
- Nt = Net terminal
- Ta = Tachometer, inside motor
- Te = Termistor NTC
- Pl = Pilot lamp
- S1 = Inlet valve
- S2/4 = Detergent/Rinse aid coil

-  = 2.8mm connection on component
-  = 6.3mm component
-  = 6.3mm component
-  = 6.3mm electronic
-  = PCB electronic
-  = Internal connection on electronic or component
-  = Connection with wire