



- Ai,f = Anti-interference filter
- b0 = Line switch
- b2 = Door switch
- b7 = Floater switch
- b9 = Salt switch
- b10 = Rinse aid switch
- f31 = Overheating protector-(boiling protector)
- f32 = Overheating thermostat
- f33 = Overheating protector
- f5.1 = Level pressostat
- H1 = Heater
- K1 = Start capacitor
- m2 = Main pump

- m3 = Drain pump
- Nt = Net terminal
- Ta = Tachometer, inside motor
- Te = Thermistor NTC
- S1 = Inlet valve
- S2/4 = Detergent/Rinse aid coil
- S3 = Regeneration valve
- S3 = 6.3mm on component
- S3 = 6.3mm on electronic PCB
- = Internal connection on electronic- or component
- = Connection with wire

EL. circuit diagram, integrated.