



This drawing contains confidential information and is the property of Electrolux. It must not be copied, shown or used in any way without the written permission of Electrolux. If these conditions are not met, the user shall be held responsible for any damage or loss. This drawing is to be returned promptly upon request to the person who issued it, which is responsible for the drawing.

$a = G_0 = 2915W$   
 $b = LR + LF = 1200 + 2300 = 3500W$   
 $c = RF + RR = 1200 + 1700/1800 = 2900/3000W$



Components =

1	R1	Radiant heater Ø145	1200W	24	-	-
2	R2	Radiant heater Ø180	1700/1800W	25	-	-
3	R3	Radiant heater Ø145	1200W	26	R13	Power resistor 2K7 17W
4	R4	Radiant heater Ø220	2300W	27	-	-
5	H4	Heat indicator		28	-	-
6	O1	Energy regulator		29	-	-
7	O2	Energy regulator		30	-	-
8	O3	Energy regulator		31	R9	Element G. oven outer 1000W
9	O4	Energy regulator		32	R10	Element G. oven inner 1900W
10	-	-		33	-	-
11	S1	Safety switch		34	-	-
12	O5	Switch Grilloven		35	R12	Element G. ugn under 1000W
13	-	-		36	H1	Indicator lamp cooker
14	T1	Thermostat oven		37	H2	Indicator lamp oven
15	-	-		38	-	-
16	E1	Oven lamp 15W G. oven		39	-	-
17	-	-		40	-	-
18	-	-		41	-	-
19	-	-		42	-	-
20	-	-		43	-	-
21	T2	Bimetal thermostat		44	-	-
22	-	-		45	-	-
23	-	-		46	X1	Terminal block

230V

When operating at 230V the LR hotplate is blocking initially if the quick-start function for the oven is in use.

MO	01005568	MO	01000888
MO	01005568	MO	01000888

MATERIAL	DESIGN OWNERS DRN	CHD	DATE	MODEL	SCALE	EUROPEAN METHOD
TREATMENT	MO	S. Ahl	01-01-20	MO	-	REPLACES NO -
WEIGHT	APPR	-	-	DERIVED FROM NO -	SUPPLY SPECIFICATIONS NO -	
TITLE				Wiring diagram		
NUMBER				305 29 90 sh1		
REV				A		

**Electrolux**