



- A. i. f = Anti-interference filter
- b0 = Line switch (MARQUARDT)
- b2 = Door switch
- b7 = Floater switch
- b9 = Salt switch
- b10 = Rinse aid switch
- b9b = Micro switch (internal light)
- f3.2 = Overheating thermostat
- f3.3 = Overheating protector
- f5.1 = Level pressostat
- H1 = Heater
- h11 = Lamp (internal light)
- K1 = Start capacitor
- m2 = Main pump
- m3 = Drain pump
- Nt = Net terminal

- Ta = Tachometer , inside motor
- Te = Termistor NTC
- T> = Turbidity sensor
- S1 = Inlet valve
- S2/4 = Detergent /Rinse aid coil
- S3 = Regeneration valve
- = b.3mm connection on component
- = PCB --- --- component
- = b.3mm --- --- electronic
- = PCB --- --- electronic